



RECOMMENDED WIRING HOOK UP FOR HONEYWELL
L4081B DUAL AQUASTAT

(Standard on the Glenwood Boilers)



HOOK UP FOR HIGH LIMIT AQUASTAT
(Activates primary* circulator on temp. rise)



*The primary circulator is the circulator which distributes the water to the radiators or heaters. Where zone valves are used, always use the zone which has the most potential of dissipating the heat.