

P/N 506015-03 Rev. G 02/2012

This manual is part of a set of three supporting this product. Refer to manual 506017-02 for Care and Operation information and 506019-40 for Facade Installation Instructions. *Ce manuel est disponible en francais, simplement en faire la demande. Numéro de la pièce 506223-05.*

INSTALLER: Leave this manual with the appliance. CONSUMER: Retain this manual for future reference.

INSTALLATEUR : Laissez cette notice avec l'appareil. CONSOMMATEUR : Conservez cette notice pour consultation ultérieure.

INSTALLATION INSTRUCTIONS

MLDVTCD Direct-Vent Contemporary Design Gas Fireplaces

MERIT^M SERIES

MODELS

<u>millivolt:</u> Mldvtcd-35NM Mldvtcd-35NM-FB

Report No. 100353019PRT-002

<u>electronic:</u> Mldvtcd-35Ne



TABLE OF CONTENTS

PackagingPage	2
IntroductionPage	2
General InformationPage	2
Requirements for the	
Commonwealth of Massachusetts . Page	4
New York City ApprovalPage	4
Cold Climate InsulationPage	5
Manufactured Home Requirements Page	5
Location Page	5
Vent Termination ClearancesPage	6
Appliance and Vent Clearances Page	8
Detailed Installation StepsPage	g
Typical Installation SequencePage	g
Step 1. FramingPage	g
Fireplace and Framing Specifications Page	10
Step 2. Routing Gas LinePage	11
Step 3. Install the Venting System Page	12
Vertical Termination SystemsPage	13
Vent Section Length ChartPage	13
Vertical Vent Tables and FiguresPage	16
Horizontal Termination System Page	17
Horizontal Vent Tables and Figures Page	20
Venting Using Flexible Vent PipePage	23
Step 4. Field WiringPage	24
Step 5. Optional Blower Kit WiringPage	25
Step 6. Connecting Gas Line Page	26
Step 7. Verifying Appliance Operation Page	27
Step 8. Installing	
Contemporary MediaPage	28
Step 9. Installing Glass DoorPage	30
Step 10. Burner Adjustments Page	30
Step 11. Hood InstallationPage	32
Finishing RequirementsPage	32
Step 12. Attaching Safety-in-	
Operation WarningsPage	
Installation AccessoriesPage	34

Please read and understand these instructions before beginning your installation.

Gas Conversion Kits.....Page 36



We recommend that our gas hearth products be installed and serviced by professionals who are certified in the U.S. by the National Fireplace Institute® (NFI) as NFI Gas Specialists.

PACKAGING

The assembled vented gas fireplace is packaged with:

- One envelope containing the literature package which consists of the care and operations manual, installation instructions, safety in operation warning labels and warranty; envelope is located in the control compartment.
- One vent restrictor to be applied as shown on *Page 12*; restrictor is taped to the envelope.
- One hood located behind the door assembly.
- One of the following contemporary floor media kits (sold separately):
 Transled Design Observed
 - a. Tumbled River Stone
 - b. Crushed Glass, Obsidian Black
 - c. Crushed Glass, Diamond White
 - d. Crushed Glass, Deep Sea Blue
 - e. White Beach Sand
- Optional Contemporary facade kits (sold separately)

INTRODUCTION

The *Millivolt* appliances have a millivolt gas control valve with piezo ignition system. If any optional accessories that will require electrical power are to be installed, the electrical power must be provided at the time of appliance installation.

The *Electronic* appliances have an electronic intermittent pilot ignition system. External electrical power is required to operate these units. The battery back-up can be used in case of a power outage.

These vented gas fireplaces are sealed combustion, air-circulating gas fireplaces designed for residential applications.

Use Only These Approved Vent Components: These fireplaces are designed, tested and listed for operation and installation with, the following (4-1/2" inner and 7-1/2" outer) vent components only:

- <u>Secure Vent</u>[™] Direct-Vent System Components manufactured by Security Chimneys International,
- Secure Flex[™] Flexible Vent Components manufactured by Security Chimneys International and
- Z-FLEX[™] Model GA Venting Systems listed to UL1777 and ULCS635 manufactured by Flexmaster Canada Limited.

These approved vent system components are labeled for identification. DO NOT use any other manufacturer's vent components with these appliances.

GENERAL INFORMATION

🛕 WARNING

Young children should be carefully supervised when they are in the same room as the appliance. Toddlers, young children and others may be susceptible to accidental contact burns. A physical barrier is recommended if there are at risk individuals in the house. To restrict access to a fireplace or stove, install an adjustable safety gate to keep toddlers, young children and other at risk individuals out of the room and away from hot surfaces.



Les jeunes enfants devraient être surveillés étroitement lorsqu'ils se trouvent dans la même pièce que l'appareil. Les tout petits, les jeunes enfants ou les adultes peuvent subir des brûlures s'ils viennent en contact avec la surface chaude. Il est recommandé d'installer une barrière physique si des personnes à risques habitent la maison. Pour empêcher l'accès à un foyer ou à un poêle, installez une barrière de sécurité; cette mesure empêchera les tout petits, les jeunes enfants et toute autre personne à risque d'avoir accès à la pièce et aux surfaces chaudes.

Children and adults should be alerted to the hazards of high surface temperature and should stay away to avoid burns or clothing ignition.

Les enfants et les adultes devraient être informés des dangers que posent les températures de surface élevées et se tenir à distance afin d'éviter des brûlures ou que leurs vêtements ne s'enflamment.

DO NOT ATTEMPT TO ALTER OR MODIFY THE CONSTRUCTION OF THE APPLIANCE OR ITS COMPONENTS. ANY MODIFICATION OR ALTERATION MAY VOID THE WARRANTY, CER-TIFICATION AND LISTINGS OF THIS UNIT.

A WARNING

Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Refer to this manual. For assistance or additional information consult a qualified installer, service agency or the gas supplier.

A WARNING

Failure to comply with these installation instructions will result in an improperly installed and operating appliance, voiding its warranty. Any change to this appliance and/or its operating controls is dangerous.

A WARNING

Clothing or other flammable material should not be placed on or near the appliance.

AVERTISSEMENT

On ne devrait pas placer de vêtements ni d'autres matières inflammables sur l'appareil ni à proximité.

🛕 WARNING

Any safety screen or guard removed for servicing the appliance must be replaced prior to operating the appliance.

AVERTISSEMENT

Tout écran ou protecteur retiré pour permettre l'entretien de l'appareil doit être remis en place avant de mettre l'appareil en marche.

A WARNING

Improper installation or use of this appliance can cause serious injury or death from fire, burns, explosion or carbon monoxide poisoning. Note: Installation and repair should be done by a qualified service person. The appliance should be inspected before use and at least annually by a professional service person. More frequent cleaning may be required due to excessive lint from carpeting, bedding material, etcetera. It is imperative that control compartments, burners and circulating air passageways of the appliance be kept clean.

Remarque : L'installation et la réparation devrait être confiées à un technicien qualifié. L'appareil devrait faire l'objet d'une inspection par un technicien professionnel avant d'être utilisé et au moins une fois l'an par la suite. Des nettoyages plus fréquents peuvent être nécessaires si les tapis, la literie, et cetera produisent une quantité importante de pous-sière. Il est essentiel que les compartiments abritant les commandes, les brûleurs et les conduits de circulation d'air de l'appareil soient tenus propres.

Do not use these appliances if any part has been under water. Immediately call a qualified, professional service technician to inspect the appliance and to replace any parts of the control system and any gas control which have been under water.

Ne pas utiliser cet appareil s'il a été plongé, même partiellement, dans l'eau. Appeler un technicien qualifié pour inspecter l'appareil et remplacer toute partie du système de commande et toute commande qui a été plongée dans l'eau.

Only trim kit(s) supplied by the manufacturer shall be used in the installation of this appliance.

Seules les trousses de garniture fournies par le fabricant doivent être utilisées pour l'installation de cet appareil.

These appliances comply with National Safety Standards and are tested and listed by ETL/ Intertek (Report No. 100353019PRT-002) to ANSI Z21.50 (in Canada, CSA-2.22), and CAN/ CGA-2.17-M91 in both USA and Canada, as vented gas fireplaces.

Both millivolt and electronic versions of these appliances are listed by ETL/Intertek for installation in bedrooms and Manufactured Homes.

Misc. Codes / Standards

The Installation must conform to local codes or, in the absence of local codes, with the *National Fuel Gas Code, ANSI Z223.1/NFPA 54 - latest edition* (In Canada, the current CAN/CSA-B149.1 installation code). The appliance, when installed, must be electrically grounded and wired in accordance with local codes or, in the absence of local codes, with the *National Electrical Code, ANSI/NFPA* 70 - *latest edition,* or the *Canadian Electrical Code, CSA C22.1* - *latest edition.*

Provide adequate clearances around air openings and adequate accessibility clearance for service and proper operation. Never obstruct the front openings of the appliance.

These appliances are designed to operate on natural or propane gas only. The use of other fuels or combination of fuels will degrade the performance of this system and may be dangerous.

These fireplaces are decorative and are designed to provide supplemental heat. Therefore, it is advisable to have an alternate primary heat source when installed in a dwelling.

These appliances must not be connected to a chimney or flue serving a separate solid fuel burning appliance.

Millivolt Models - The millivolt appliances are manually controlled and feature a spark igniter (piezo) that allows the appliance's pilot gas to be lit without the use of matches or batteries. This system provides continued service in the event of a power outage.

Millivolt models come standard with a manually-modulated gas valve; flame appearance and heat output can be controlled at the gas valve. The BTU Input for these appliances is shown in *Table 1*.

Electronic Models - These electronic appliances are manually controlled and feature an electronic intermittent pilot ignition system. External electrical power is required to operate these units.

These electronic models come standard with a manually-modulated gas valve; flame appearance and heat output can be controlled at the gas valve. The BTU Input for these appliances is shown in *Table 1*.

<u>Input (BTU/HR)</u> Manually-Modulated Gas Valves (all models)				
Input Rate (BTU / HR)				
Models	Nat. Gas	Prop. Gas		
MLDVTCD-35 14,500 high 13,500 high 11,500 low 10,500 low				
Table 1				

Gas Pressure - All Models

Tables 2 and 3 show the appliances' gas pressure requirements:

Inlet Gas Supply Pressure (all models)					
Fuel # Minimum Maximum					
Natural Gas 4.5" WC (1.12 kPa) 10.5" WC (2.61 kPa)					
Propane 11.0" WC 13.0" WC (2.74 kPa) (3.23 kPa)					
Table 2					

Manifold Gas Supply Pressure (all models)					
Fuel #	Low	High			
Natural Gas	(Lo) 2.2" WC (0.55 kPa)	(Hi) 3.5" WC (0.87 kPa)			
Propane (Lo) 6.3" WC (Hi) 10.0" WC (1.57 kPa) (2.49 kPa)					
Table 3					

Test gauge connections are provided on the front of the millivolt and electronic gas control valve (identified IN for the inlet and OUT for the manifold side). The control valves have a 3/8" (10mm) NPT thread inlet and outlet side of the valve.

Propane tanks are at pressures that will cause damage to valve components. Verify that the tanks have step down regulators to reduce the pressure to safe levels.

These appliances must be isolated from the gas supply piping system (*by closing their individual manual shut-off valve*) during any pressure testing of the gas supply piping system at test pressures equal to or **less than** 1/2 psig (3.5 kPa).

These appliances and their individual shut-off valves *must be disconnected* from the gas supply piping system during any pressure testing of that system at pressures **greater than** 1/2 psig (3.5 kPa).

These appliances must not be connected to a chimney or flue serving a separate solid fuel burning appliance.

Orifice Sizes - Sea Level to High Altitude (All Models)

These appliances are tested and approved for installation at elevations of 0-4500 feet (0-1372 meters) above sea level using the standard burner orifice sizes (marked with an "*" in **Table 4**). For elevations above 4500 feet, contact your gas supplier or qualified service technician.

Deration - At higher elevations, the amount of BTU fuel value delivered must be reduced by either:

- Using gas that has been derated by the gas company.
- Changing the burner orifice to a smaller size as regulated by the local authorities having jurisdiction and by the (USA) National Fuel Gas Code NFPA 54/ANSI Z223.1 - latest edition or, in Canada, the CAN/CSA-B149.1 codes - latest edition.

Install the appliance according to the regulations of the local authorities having jurisdiction and, in the USA, the National Fuel Gas Code NFPA 54 / ANSI Z223.1 - latest edition or, in Canada, the CAN/CSA-B149.1 - latest edition.

NOTE: Flame appearance will diminish 4% per thousand feet.

Burner Orifice Sizes Elevation 0-4500 feet (0-1372 meters)					
Model Nat.Gas Propane Series drill size (inches) drill size (inches)					
MLDVTCD-35 #49 (0.073") * 0.045" ** 21L82 • 75L10 •					
* Standard size installed at factory ** Standard size in LP conversion kit • Part /Cat. Number					

Gas Valve Diagrams

See *Figure 1* for Millivolt models and *Figure 2* For Electronic Models.





REQUIREMENTS FOR THE COMMON-WEALTH OF MASSACHUSETTS

These fireplaces are approved for installation in the US state of Massachusetts if the following additional requirements are met:

- Install this appliance in accordance with Massachusetts Rules and Regulations 248 C.M.R.
- Installation and repair must be done by a plumber or gas fitter licensed in the Commonwealth of Massachusetts.
- The flexible gas line connector used shall not exceed 36 inches (92 centimeters) in length.
- The individual manual shut-off must be a T-handle type valve.

Massachusetts Horizontal Vent Requirements

In the Commonwealth of Massachusetts, horizontal terminations installed less than seven (7) feet above the finished grade must comply with the following additional requirements:

- A hard wired carbon monoxide detector with an alarm and battery back-up must be installed on the floor level where the gas fireplace is installed. The carbon monoxide detector must comply with NFPA 720, be ANSI/UL 2034 listed and be ISA certified.
- A metal or plastic identification plate must be permanently mounted to the exterior of the building at a minimum height of eight (8) feet above grade and be directly in line with the horizontal termination. The sign must read, in print size no less than one-half (1/2) inch in size, GAS VENT DIRECTLY BELOW. KEEP CLEAR OF ALL OBSTRUCTIONS.

NEW YORK CITY, NEW YORK (MEA)

Installation of these fireplaces are approved for installation in New York City in the US state of New York.

COLD CLIMATE INSULATION

For cold climate installations, seal all cracks around your appliance with noncombustible material and wherever cold air could enter the room. It is especially important to insulate outside chase cavity between studs and under floor on which appliance rests, if floor is above ground level. Gas line holes and other openings should be caulked or stuffed with unfaced fiberglass insulation.

If the fireplace is being installed on a cement slab in cold climates, a sheet of plywood or other raised platform can be placed underneath to prevent cold transfer to the fireplace and into the room. It also helps to sheetrock inside surfaces and tape for maximum air tightness and caulk firestops.

MANUFACTURED HOME REQUIREMENTS

This appliance may be installed in an aftermarket permanently located, manufactured home and must be installed in accordance with the manufacturer's instructions and the Manufactured Home Construction and Safety Standard, Title 24 CFR, Part 3280, in the United States, or the Standard for Installation in Mobile Homes, CAN/CSA Z240 MH Series, in Canada.

Cet appareil peut être installé cómme du matériel d'origine dans une maison préfabriquée (É.U. seulement) ou mobile et doit être installé selon les instructions du fabricant et conformément à la norme Manufactured Home Constructions and Safety, Title 24 CFR, Part 3200 aux Unis ou à la norme Can/CSA-Z240 Série MM, Maisons mobiles au Canada.

This appliance is only for use with the type of gas indicated on the rating plate. This appliance is not convertible for use with other gases, unless a certified kit is used.

Cet appareil doit être utilisé uniquement avec le type de gaz indiqué sur la plaque signalétique. Cet appareil ne peut être converti à d'autres gaz, sauf si une trousse de conversion est utilisée.

CAUTION: Ensure that the cross members are not cut or weakened during installation. The structural integrity of the manufactured home floor, wall, and ceiling / roof must be maintained.

CAUTION: This appliance must be grounded to the chassis of the manufactured home in accordance with local codes or in the absence of local codes, with the National Electrical Code ANSI / NFPA 70 - latest edition or the Canadian Electrical Code CSA C22.1 - latest edition.



LOCATION

In selecting the location, the aesthetic and functional use of the appliance are primary concerns. However, vent system routing to the exterior and access to the fuel supply are also important.

Due to high temperatures, the appliance should be located out of traffic and away from furniture and draperies (Figure 3).

En raison des températures élevées, l'appareil devrait être installé dans un endroit où il y a peu de circulation et loin du mobilier et des tentures (Figure 3).

The location should also be free of electrical, plumbing or other heating/air conditioning ducting.

These direct-vent appliances are uniquely suited for installations requiring a utility shelf positioned directly above the fireplace. Utility shelves like these are commonly used for locating television sets and decorative plants. Be aware that this is a heat producing appliance. Objects placed above the unit are exposed to elevated temperatures.

Do not insulate the space between the appliance and the area above it *(see Figure 7 on Page 8)*.

The minimum height from the base of the appliance to the underside of combustible materials used to construct a utility shelf in this fashion is shown in *Figure 7 on Page 8*.

The appliance should be mounted on a fully supported base extending the full width and depth of the unit. The appliance may be located on or near conventional construction materials. However, if installed on combustible materials, such as carpeting, vinyl tile, etc., a metal or wood barrier covering the entire bottom surface must be used.

VENT TERMINATION CLEARANCES

These instructions should be used as a guideline and do not supersede local codes in any way. Install venting according to local codes, these instructions, the current National Fuel Gas Code (ANSI-Z223.1) in the USA or the current standards of CAN/CSA-B149.1 in Canada.

Vertical Vent Termination Clearances

Terminate multiple vent terminations according to the installation codes listed above. Also see *Figure 4A*.

Terminate single vent caps relative to building components according to *Figure 4B*.



Figure 4A - Multiple Terminations

Vertical Vent Termination Clearances



The vent / air intake termination clearances above the high side of an angled roof is as shown in the following chart:

Termination Heights For Vents Above Flat Or Sloped Roofs Ref. NFPA 54 / ANSI Z223.1				
Roof Pitch	* Feet	* Meters		
Flat to 6/12	1.0	0.3		
6/12 to 7/12	1.25	0.38		
7/12 to 8/12	1.5	0.46		
8/12 to 9/12	2.0	0.61		
9/12 to 10/12	2.5	0.76		
10/12 to 11/12	3.25	0.99		
11/12 to 12/12	4.0	1.22		
12/12 to 14/12	5.0	1.52		
14/12 to 16/12	6.0	1.83		
16/12 to 18/12	7.0	2.13		
18/12 to 20/12	7.5	2.29		
20/12 to 21/12	8.0	2.44		

Figure 4B

Horizontal Vent Termination Clearances

The horizontal vent termination must have a minimum of 6" (152 mm) clearance to any overhead combustible projection of 2-1/2" (64 mm) or less. See *Figure 5.* For projections exceeding 2-1/2" (64 mm), see *Figure 5*. For additional vent location restrictions refer to *Figure 6* on *Page 7*.





	Canadian Installation*	US Installation**
A = Clearance above grade, veranda, porch, deck, or balcony.	12 inches (30cm)*	12 inches (30cm)**
B = Clearance to window or door that may be opened.	6 inches (15cm) for appliances < 10,000 Btuh (3kW), 12 inches (30cm) for appliances > 10,000 Btuh (3kW)	6 inches (15cm) for appliances < 10,000 Btuh (3kW), 9 inches (23cm) for appliances > 10,000 Btuh (3kW) and < 50,000 Btuh (15kW), 12 inches (30cm) for appliances > 50,000 Btuh (15kW)**
C = Clearance to permanently closed window	12 inches (305mm) recommended to prevent window condensation	9 inches (229mm) recommended to prevent window condensation
D = Vertical clearance to ventilated soffit located above the termination within a horizontal distance of 18 inches (458mm) from the center line of the termination	18 inches (458mm)	18 inches (458mm)
E = Clearance to unventilated soffit***	12 inches (305mm)	12 inches (305mm)
F = Clearance to outside corner	5 inches (12.7cm) minimum	5 inches (12.7cm) minimum
G = Clearance to inside corner (Refer to Figure 5)	6 inches (15.2cm) minimum	6 inches (15.2cm) minimum
H = Clearance to each inside of center line extended above meter/regulator assembly	3 feet (91cm) within a height of 15 feet above the meter/regulator assembly*	3 feet (91cm) within a height of 15 feet above the meter/regulator assembly**
I = Clearance to service regulator vent outlet	3 feet (91cm)*	3 feet (91cm)**
J = Clearance to nonmechanical air supply inlet to building or the combustion air inlet to any other appliance	6 inches (15cm) for appliances < 10,000 Btuh (3kW), 12 inches (30cm) for appliances > 10,000 Btuh (3kW)	6 inches (15cm) for appliances < 10,000 Btuh (3kW), 9 inches (23cm) for appliances > 10,000 Btuh (3kW) and < 50,000 Btuh (15kW), 12 inches (30cm) for appliances > 50,000 Btuh (15kW)**
K = Clearance to a mechanical air supply inlet	6 feet (1.83m)*	3 feet (91cm) above if within 10 feet (3m) horizontally**
${\bf L}$ = Clearance above paved sidewalk or paved diveway located on public property	7 feet (2.13m)‡	7 feet (2.13m)‡
M = Clearance under veranda, porch, deck or balcony	12 inches (30cm)*‡	12 inches (30cm)‡
N = Depth of Alcove (Maximum)	6 feet (1.83m)*	6 feet (1.83m)**
0 = Clearance to Termination (Alcove)	6 inches (15.2mm)*	6 inches (15.2mm)**
P = Width of Alcove (Minimum)	3 feet (91cm)*	3 feet (91cm)*
Q = Clearance to Combustible Above (Alcove)	18 inches (457mm)*	18 inches (457mm)**
* In accordance with the current CAN/CSA-B149.1 National Gas	And Propane Installation Code.	1 · · ·

* In accordance with the current CAN/CSA-B149.1 National Gas And Propane Installation Code.

** In accordance with the curent ANSI SZ223.1/NFPA 54 National Fuel Gas Codes.

*** Clearance required to vinyl soffit material - 30 inches (76cm) minimum.

+ A vent shall not terminate directly above a sidewalk or paved driveway which is located between two single family dwellings and serves both dwellings.

*‡ Only permitted if veranda, porch, deck or balcony is fully open on a minimum 2 sides beneath the floor:

NOTE: DIAGRAMS & ILLUSTRATIONS ARE NOT TO SCALE.

MINIMUM CLEARANCES TO COMBUSTIBLES

Appliance And Vent Clearances

The appliance is approved with zero clearance to combustible materials on all sides (as detailed in *Table 5)*, with the following exception: When the unit is installed with one side flush with a wall, the wall on the other side of the unit must not extend beyond the front edge of the unit. In addition, when the unit is recessed, the side walls surrounding the unit must not extend beyond the front edge of the unit (see *Figure 3*).

MINIMUM CLEARANCES* Inches (millimeters)			
Back	0 (0) Spacers Or Dimples		
Sides	1/2 (13)** 0 (0) Spacers or Dimples		
Тор	3 (76)		
Floor	0 (0)		
From Bottom of Unit To Ceiling	64 (1626)		
Vent 3 (76) Top* / 1 (25.4) Sides & Botto			
SERVICE CLEARANCES Feet (meters)			
Front 3 feet (0.9 meters)			
Table 5			

*Note: 3 in. (75 mm) above any horizontal/inclined vent component.

**Note: See Page 9, Step 1 for clearance requirements to the nailing flange located at each side of the unit and any screw heads adjacent to it.

Hearth Extension A hearth extension is not required with this appliance. If a hearth extension is used, do not block the lower control compartment door. Any hearth extension used is for appearance only and does not have to conform to standard hearth extension installation requirements.

Shelf Height - To provide for the lowest possible shelf surface, the venting attached to the top vent should be routed in a way to minimize obstructions to the space above the appliance. Do not insulate the space between the appliance and the area above it (see *Figure 7*). The minimum height from the base of the appliance to the underside of combustible materials used to construct a utility shelf in this fashion is shown in *Figure 7*.

Wall Finishes / Surrounds / Mantels

Note: Combustible wall finish materials and/or surround materials must not be allowed to encroach the area defined by the appliance front face (black sheet metal). **Never allow combustible materials to be positioned** *in front of or overlapping the appliance front face* (see **Figure 47** on **Page 32**).

Non-combustible materials, such as surrounds and other appliance trim, may be installed on the appliance face with these exceptions: they must not cover any portion of the removable glass panel.

Vertical installation clearances to combustible mantels vary according to the depth of the mantel. See *Figure 8*. Mantels constructed of non-combustible materials may be installed at any height above the appliance opening; however, do not allow anything to hang below the hood.

NOTE: We recommend the use of high temperature paint (rated 175° F or higher) on the underside of the mantel.











🛕 WARNING

Failure to position the parts in accordance with these diagrams or failure to use only parts specifically approved with this appliance may result in property damage or personal injury.

AVERTISSEMENT

Risque de dommages ou de blessures si les pièces ne sont pas installées conformément à ces schémas et ou si des pièces autres que celles spécifiquement approuvées avec cet appareil sont utilisées.

DETAILED INSTALLATION STEPS

The appliance is shipped with all gas controls and components installed and pre-wired.

- 1.Remove the shipping carton. Remove the shipping pad, exposing the front glass door.
- 2. Open the two latches (located under the firebox floor) securing the glass door. Remove the door by tilting it outward at the bottom and lifting it up. Set the door aside protecting it from inadvertent damage. *See Removing Glass Panels* on **Page 30**.

TYPICAL INSTALLATION SEQUENCE

The typical sequence of installation is outlined below. However, each installation is unique and may result in variations to the steps described.

See the Page numbers references in the following steps for detailed procedures.

- Step 1. (Pages 10 and 11) Construct the appliance framing. Position the appliance within the framing and secure with nailing brackets. Bend up the appropriate header spacing guides for the drywall/finish material thickness to be used (see Figure 47 on Page 32). Bend up the outer pair for 1/2" materials and the inner pair for 5/8" materials. Bend out the appropriate nailing flanges for the drywall/finish material to be used. Nailing flanges are provided for flush framing, 1/2 inch and 5/8 inch framing depths (see Figure 10).
- **Step 2.** (*Page 11*) Route gas supply line to appliance location.
- **Step 3.** (*Page 12*) Install the vent system and exterior termination.
- Step 4. (Page 24) Field Wiring

 a. Millivolt Appliances Bring in electrical service line for forced aircirculating blower (optional equipment).
- b. Electronic Appliances Field wire.
 Step 5. (*Page 25*) Install blower kit (optional equipment).
- Step 6. (*Page 26*) Make connection to gas supply.
- Step 7. (Page 27) Verify appliance operation.
- Step 8. (Page 28) Install contemporary media.
- Step 9. (Page 30) Install glass door assembly.
- **Step 10.** (*Page 30*) Adjust burner primary air shutter to achieve proper flame appearance.
- Step 11. (Page 32) Install the hoods.
- Step 12. (Page 33) Attach Safety in Operation Warnings.

Step 1. FRAMING

Frame these appliances as illustrated in *Figures 11 and 12* on *Pages 10 and 11* (*Figure 12* applies to corner framing installations only). All framing details must allow for a minimum clearance to combustible framing members as shown in *Table 5 on Page 8*.

If the appliance is to be elevated above floor level, a solid continuous platform must be constructed below the appliance.

Headers may be in direct contact with the appliance top spacers when they are bent up vertically maintaining the 3" clearance to the fireplace top, but must not be supported by them or notched to fit around them. All construction above the appliance must be self-supporting. **DO NOT** use the appliance for structural support.

The fireplace should be secured to the side framing members using the unit's nailing flanges - one top and bottom on each side of the fireplace front. See *Figure 10.* Use 8d nails or their equivalent.



FIREPLACE AND FRAMING SPECIFICATIONS





Vertical Venting Through the Ceiling:

Frame ceiling opening - Use a plumb line from the ceiling above the appliance to locate center of the vertical run. Cut and/or frame an opening, $10-1/2" \times 10-1/2"$ (267 mm × 267 mm) inside dimensions, about this center mark *(see Figure 16 on Page 14)*.



FIREPLACE FRAMING SPECIFICATIONS



Step 2. ROUTING GAS LINE

Route a 1/2" (13mm) gas line to the left side of the appliance as shown in *Figure 13*. Gas lines must be routed, constructed and made of materials that are in strict accordance with local codes and regulations. All appliances are factory-equipped with a flexible gas line connector and 1/2 inch shutoff valve (*see Step 6 on Page 26*).



Proper Sizing of Gas Line

Properly size and route the gas supply line from the supply regulator to the area where the appliance is to be installed per requirements outlined in the National Fuel Gas Code, NFPA 54 - latest edition (USA) or CAN/CSA-B149.1 - latest edition (Canada). Never use galvanized or plastic pipe. Refer to **Table 6** for proper sizing of the gas supply line, if black iron pipe is being used. Gas lines must be routed, constructed and made of materials that are in strict accordance with local codes and regulations. We recommend that a qualified individual such as a plumber or gas fitter be hired to correctly size and route the gas supply line to the appliance. Installing a gas supply line from the fuel supply to the appliance involves numerous considerations of materials, protection, sizing, locations, controls, pressure, sediment, and more. Certainly no one unfamiliar and unqualified should attempt sizing or installing gas piping.

Schedule 40 Black Iron Pipe Inside Diameter (Inches)					
Schedule40 PipeNaturalPropaneLength (feet)GasGas					
0-10	1/2	3/8			
10-40	1/2	1/2			
40-100	1/2	1/2			
100-150	3/4	1/2			
150-200 3/4 1/2					
Table 6					

Notes:

- All appliances are factory-equipped with a flexible gas line connector and 1/2 inch shutoff valve (see *Figure 38* on *Page 26*).
- See *Massachusetts Requirements* on *Page 4* for additional requirements for installations in the state of Massachusetts in the USA.
- The gas supply line should Not be connected to the appliance until *Step 6 (Page 26)*.
- A pipe joint compound rated for gas should be used on the threaded joints. Ensure propane resistant compounds are used in propane applications. Be very careful that the pipe compound does not get inside the pipe.
- It is recommended to install a sediment trap in the supply line as close as possible to the appliance. Appliances using Propane should have a sediment trap at the base of the tank.
- Check with local building official for local code requirements (i.e. are below grade penetrations of the gas line allowed?, etc).

IMPORTANT: If propane is used, be aware that if tank size is too small (i.e. under 100-lbs, if this is the only gas appliance in the dwelling. Ref. NPFA 58), there may be loss of pressure, resulting in insufficient fuel delivery (which can result in sooting, severe delayed ignition or other malfunctions). Any damage resulting from an improper installation, such as this, is not covered under the limited warranty.

Step 3. INSTALL THE VENT SYSTEM

General Information

These instructions should be used as a guideline and do not supersede local codes in any way. Install venting according to local codes, these instructions, the current National Fuel Gas Code (ANSI-Z223.1) in the USA or the current standards of CAN/CSA-B149.1 in Canada.

Clearance in accordance with local installation codes and the requirements of the gas supplier.

Dégagement conforme aux codes d'installation locaux et aux exigences du foumisseunde gaz.

Use only approved venting components. See *Approved Vent Components* on *Page 2.*

These fireplaces must be vented directly to the outside.

The vent system may not service multiple appliances, and must never be connected to a flue serving a solid fuel burning appliance. The vent pipe is tested to be run inside an enclosed wall (such as a chase). There is no requirement for inspection openings in the enclosing wall at any of the joints in the vent pipe.

Installation of Vent Restrictor

A vent restrictor may be needed with this appliance. The restrictor is installed in the appliance top flue outlet as shown in *Figure* 14, either before adding vent, from above, or after installation of vent from below, within the firebox. The restrictor is self securing through a positive friction fit.

Determine the venting for the appliance. If the vent run will include at least 8 feet of vertical rise, then install the restrictor in the appliance collar before connecting any vent *(Refer to Figure 14).* Place the restrictor inside the appliance vent collar and press in place.

Note: The restrictor is included within the firebox.

Vent Restrictor Installation (Top Vent)

A vent restrictor may be needed when vertically terminating the vent system above the roof (when using the appliance top vent), install vent restrictor in the top vent of the fireplace outlet on all MLDVTCD series models. If needed, install the restrictor orientated as shown, either from inside or outside the unit, in the inner fireplace collar.



Select Venting System - Horizontal or Vertical

With the appliance secured in framing, determine vent routing and identify the exterior termination location. The following sections describe vertical (roof) and horizontal (exterior wall) vent applications. Refer to the section relating to your installation. A list of approved venting components is shown on *Pages 34 and 35*.

Note: It is not recommended that this unit be vented more than forty feet (40') vertically. Extended vertical vent runs will diminish the fire.

VERTICAL TERMINATION SYSTEMS (ROOF)

See Figure 15 on Page 13 and Figures 23-25 on Pages 16 and 17 and their associated Vertical Vent Tables which illustrate the various vertical venting configurations that are possible for use with these appliances. Secure Vent[™] pipe applications are shown in these Figures; Secure Flex[™] pipe may also be used. A Vertical Vent Table summarizes each system's minimum and maximum vertical and horizontal length values that can be used to design and install the vent components in a variety of applications.

Both these vertical vent systems terminate through the roof. The minimum vent height above the roof and/or adjacent walls is specified in ANSI Z223.1-(latest edition) (In Canada, the current CAN/CSA-B149.1 installation code) by major building codes. Always consult your local codes for specific requirements. A general guide to follow is the Gas Vent Rule (refer to *Figure 4B on Page 6*).

A vent restrictor may need to be installed when vertical termination is used. See *Installation of Vent Restrictor* on **Page 12** for guidelines.

Vertical (Straight) Installation

Determine the number of straight vent sections required. 4-1/2" (114 mm), 10-1/2" (267 mm), 22-1/2" (572 mm), 34-1/2" (876 mm) and 46-1/2" (1181 mm) net section lengths are available (see **Tables on this page** and **Page 34 - Vent Sections)**. It is recommended that you plan the vent lengths so that a joint does not occur at the intersection of ceiling or roof joists. Refer to the Vent Section Length Chart.



VENT SECTION LENGTH CHART							
Nom Section (incl Net S	Length hes)	6	12	24	36	48	T O T A
Length (ection (inches)	4-1/2	10-1/2	22-1/2	34-1/2	46-1/2	Ιî.
Height	Height of Vent		lumber	of Vent	Section	s	Q
inches	ft						ł
4.5	0.375	1	0	0	0	0	1
9	0.75	2	0	0	0	0	2
10.5	0.875	0	1	0	0	0	1
15	1.25	1	1	0	0	0	2
19.5	1.625	2	1	0	0	0	3
21	1.75	0	2	0	0	0	2
22.5	1.875	0	0	1	0	0	1
25.5	2.125	1	2	0	0	0	3
31.5	2.625	0	3	0	0	0	3
34.5	2.875	0	0	0	1	0	1
37.5	3.125	1	1	1	0	0	3
43.5	3.625	0	2	1	0	0	3
45	3.75	0	0	2	0	0	2
46.5	3.875	0	0	0	0	1	1
49.5	4.125	1	0	2	0	0	3
51	4.25	1	0	0	0	1	2
55.5	4.625	0	1	2	0	0	3
57	4.75	0	0	1	1	0	2
66	5.25	0	2	2	0	0	4
67.5	5.625	0	0	3	0	0	3
69	5.75	0	0	0	2	0	2
72	6	1	0	3	0	0	4
73.5	6.125	1	0	0	2	0	3
79.5	6.625	0	1	0	2	0	3
81	6.75	0	0	0	1	1	2
90	7.5	0	2	1	0	1	4
91.5	7.625	0	0	2	0	1	3
93	7.75	0	0	0	0	2	2
96	8	1	0	1	2	0	4
97.5	8.125	1	0	0	0	2	3
102	8.5	2	0	0	0	2	4
103.5	8.625	0	0	0	3	0	3
108	9	1	0	0	3	0	4
114	9.5	0	2	0	0	2	4
117	9.75	1	0	5	0	0	6
118.5	9.875	1	1	0	3	0	5
126	10.5	0	0	1	3	0	4
130.5	10.875	1	0	1	3	0	5
135	11.25	0	0	6	0	0	6
138	11.5	0	0	0	4	0	4
139.5	11.625	0	0	0	0	3	3
142.5	11.875	1	0	0	4	0	5

VENT SECTION LENGTH CHART							
	l Section (inches)	6	12	24	36	48	Ţ
	Section (inches)	4-1/2	10-1/2	22-1/2	34-1/2	46-1/2	Ă
	Height of Vent		Number	of Vent	Section	s	Q
inches	ft						Ĭ
144	12	1	0	0	0	3	4
150	12.5	0	1	0	0	3	4
154.5	12.875	1	1	0	0	3	5
160.5	13.375	0	2	0	0	3	5
172.5	14.375	0	0	0	5	0	5
177	14.75	1	0	0	5	0	6
183	-	0	1	0	5	-	
	15.25	-		-	-	0	6
186	15.5	0	0	0	0	4	4
190.5	15.875	1	0	0	0	4	5
196.5	16.375	0	1	0	0	4	5
205.5	17.125	0	1	1	5	0	7
207	17.25	0	0	0	6	0	6
211.5	17.625	1	0	0	6	0	7
217.5	18.125	0	1	0	6	0	7
229.5	19.125	0	0	1	6	0	7
232.5	19.375	0	0	0	0	5	5
237	19.75	1	0	0	0	5	6
241.5	20.125	0	0	0	7	0	7
246	20.5	1	0	0	7	0	8
252	21	0	1	0	7	0	8
264	22	0	0	1	7	0	8
276	23	0	0	0	8	0	8
279	23.25	0	0	0	0	6	6
280.5	23.375	1	0	0	8	0	9
283.5	23.625	1	0	0	0	6	7
289.5	24.125	0	1	0	0	6	7
301.5	25.125	0	0	1	0	6	7
310.5 315	25.875	0	0	0	9 9	0	9 10
325.5	26.5 27.125	0	0	0	9	7	7
330	27.123	1	0	0	0	7	7 8
336	28	0	1	0	0	7	8
345	28.75	0	0	0	10	0	10
349.5	29.125	1	0	0	10	0	11
372	31	0	0	0	0	8	8
376.5	31.375	1	0	0	0	8	9
379.5	31.625	0	0	0	11	0	11
418.5	34.875	0	0	0	0	9	9
423	35.25	1	0	0	0	9	10
465	38.75	0	0	0	0	10	10

Note: Convert inches into metric equivalent measurement, as follows:

Millimeters (mm) = Inches x 25.4 Centimeters (cm) = Inches x 2.54 Meters (M) = Inches x .0254

Effective Vent Length				
Model Effective Length				
SV4.5L6 4-1/2"				
SV4.5L12 10-1/2"				
SV4.5L24 22-1/2"				
SV4.5L36 34-1/2"				
SV4.5L48 46-1/2"				
Table 7				

Vertical (Offset) Installation

Analyze the vent routing and determine the quantities of vent sections and number of elbows required. Refer to **Vertical Vent Figures and Tables on Pages 16 and 17** to select the type of vertical installation desired. Vent sections are available in net lengths of 4-1/2" (114 mm), 10-1/2" (267 mm), 22-1/2" (572 mm), 34-1/2" (876 mm) and 46-1/2" (1181 mm). Refer to the **Vent Section Length Charts on Page 13** for an aid in selecting length combinations. Elbows are available in 90° and 45° configurations. Refer to **Figure 19 on Page 15** for the SV4.5E45 and SV4.5E90 elbow dimensional specifications.

Where required, a **telescopic vent section (SV4.5LA)** may be used to provide the installer with an option in installing in tight and confined spaces or where the vent run made up of fixed length pieces develops a joint in a undesirable location, or will not build up to the required length. The SV4.5LA Telescopic Vent Section has an effective length of from 1-1/2" (38 mm) to 7-1/2" (191 mm). The SV4.5LA is fitted with a locking inclined channel end (identical to a normal vent section component) and a plain end with 3 pilot holes. Slip the plain end over the locking channel end of a standard SV4.5 vent component the required distance and secure with three screws.

Maintain a minimum 1" (25 mm) clearance to combustible materials for all vertical elements. Clearances for all horizontal elements are 3" (76 mm) on top, 1" (25 mm) on sides and 1" (25 mm) on the bottom.

A. Frame ceiling opening - Use a plumb line from the ceiling above the appliance to locate center of the vertical run. Cut and/or frame an opening, $10-1/2" \times 10-1/2"$ (267mm x 267mm) inside dimensions, about this center mark (*Figure 16*).



B. Attach vent components to appliance - Secure Vent SV4.5 direct-vent system components are unitized concentric pipe components featuring positive twist lock connections (*see Figure 17*).

All of the appliances covered in this document are fitted with collars having locking inclined channels. The dimpled end of the vent components fit over the appliance collar to create the positive twist lock connection.

Arrow 7	Align the din upper vent so of the locking the lower ver collar. Twist clockwise to arrow and di	ection with g incline c nt section vent com engage a	i thé opening hannel on or appliance ponent 1d seal until
	Dimple Locking Incline Channel Connecte Sections		Arrow
Appliance Vent Sect			
Figure 17			

To attach a vent component to the appliance collar, align the dimpled end over the collar, adjusting the radial alignment until the four locking dimples are aligned with the inlet of the four inclined channels on the collar (*refer to Figure 17*). Push the vent component against the collar until it fully engages, then twist the component clockwise, running the dimples down and along the incline channels until they seat at the end of the channels. The unitized design of the **Secure Vent**TM components will engage and seal both the inner and outer pipe without the need for sealant or screws. If desired, a #6 x 1/2" screw may be used at the joint, but is not required as the pipe will securely lock when twisted.

Note: An elbow may also be attached to the appliance collar. Attach in the same manner as you would a vent section.

C. Attach vent components to each other - Other vent sections may be added to the previously installed section in accordance with the requirements of the vertical vent Figures and Tables. To add another vent component to a length of vent run, align the dimpled end over the inclined channel end of the previously installed section, adjusting the radial alignment until the four locking dimples are aligned with the inlets of the four incline channels of the previous section. Push the vent component against the previous section until it fully engages, then twist the component clockwise running the dimples down and along the incline channels until they seat at the end of the channels. This seating position is indicated by the alignment of the arrow and dimple as shown in *Figure 17*.

D. Install firestop/spacer at ceiling - When using Secure Vent, use SV4.5VF firestop/spacer at ceiling joists; when using Secure Flex, use SF4.5VF firestop/spacer. If there is living space above the ceiling level, the firestop/spacer must be installed on the bottom side of the ceiling. If attic space is above the ceiling, the firestop/spacer must be installed on the top side of the joist.

Route the vent sections through the framed opening and secure the firestop/spacer with 8d nails or other appropriate fasteners at each corner. Remember to maintain 1" (25 mm) clearance to combustibles, framing members, and attic or ceiling insulation when running vertical chimney sections. Attic insulation shield (H3907) may be used to obtain the required clearances indicated here. See installation accessories Pages 34 and 35. The gap between the vent pipe and a vertical firestop can be sealed with noncombustible caulking.

E. Support the vertical vent run sections -

Note - Proper venting support is very important. The weight of the vent must not be supported by the fireplace in any degree.

Support the vertical portion of the venting system every 8 feet (2.4m) above the fireplace vent outlet.



One method of support is by utilizing field provided support straps (conventional plumber's tape). Secure the plumber's tape to the framing members with nails or screws. Loop the tape around the vent, securing the ends of the tape to the framing. If desired, sheet metal screws #6 $\times 1/2^{"}$ length may be used to secure the support straps to the vent pipe. Refer to *Figure 18*.

F. Change vent direction to horizontal/inclined run - At transition from or to a horizontal/in-

clined run, install the SV4.5E45 and SV4.5E90 elbows in the same manner as the straight vent sections. The elbows feature a twist section to allow them to be routed about the center axis of their initial collar section to align with the required direction of the next vent run element. **Twist elbow sections in a clockwise direction** only so as to avoid the possibility of unlocking any of the previously connected vent sections (see Figure 19).



G. Continue installation of horizontal/inclined sections - Continue with the installation of the straight vent sections in horizontal/inclined run as described in Step C. Install support straps every 5 ft. (1.52 m) along horizontal/inclined vent runs using conventional plumber's tape. See Page 18, Figure 26. It is very important that the horizontal/inclined run be maintained in a straight (no dips) and recommended to be in a slightly elevated plane, in a direction away from the fireplace of 1/4 " rise per foot (20 mm per meter) which is ideal, though rise per foot run ratios that are smaller are acceptable all the way down to at or near level. Use a carpenter's level to measure from a constant surface and adjust the support straps as necessary.

It is important to maintain the required clearances to combustibles: 1"(25mm) at all sides for all vertical runs; and 3"(76mm) at the top, 1"(25mm) at sides, and 1"(25mm) at the bottom for all horizontal/inclined runs.

H. Frame roof opening - Identify location for vent at the roof. Cut and/or frame opening per Roof Framing Chart (*Figure 20*).



Figure 20 - Roof Framing

I. Install the roof flashing - Extend the vent sections through the roof structure. Install the roof flashing over the vent section and position such that the vent column rises vertically (use carpenters level) (*Figure 21*). Nail along perimeter to secure flashing or adjust roofing to overlap the flashing edges at top and sides only and trim where necessary. Seal the top and both sides of the flashing with waterproof caulking.

J. Install the storm collar - Install the storm collar, supplied with the flashing, over the vent/flashing joint. See *Figure 21*. Loosen the storm collar screw. Slide collar down until it meets the top of the flashing. Tighten the adjusting screw. Apply non-combustible caulking or mastic around the circumference of the joint to provide a water tight seal.



K. Install the vertical termination - The final step involves installation of the SV4.5CGV-1 Vertical Termination. Extend the vent sections to the height as shown in the "Vertical vent termination section" in Figure 4B on Page 6. The SV4.5CGV-1 Vertical Termination (Figure 22) can be installed in the exact same fashion as any other Secure Vent[™] section. Align the termination over the end of the previously installed section, adjusting the radial alignment until the four locking dimples of the termination are aligned with the inlets of the four incline channels of the last vent section. Push the termination down until it fully engages, then twist the termination clockwise running the dimples down and along the incline channels until they are seated at the end of the channels.



If the vent system extends more than 5 feet (1.5 m) above the roof flashing, stabilizers may be necessary. Additional screws may be used at section joints for added stability. Guide wires may be attached to the joint for additional support on multiple joint configurations.

VERTICAL VENT FIGURES/TABLES

Notes:

- Secure Vent[™] (rigid vent pipe) is shown in the Figures; Secure Flex[™] (flexible vent pipe) may also be used.
- It is very important that the horizontal/inclined run be maintained in a straight (no dips) and recommended to be in a slightly elevated plane, in a direction away from the fireplace of 1/4" rise per foot (20 mm per meter) which is ideal, though rise per foot run ratios that are smaller are acceptable all the way down to at or near level.
- SV4.5VF (Secure Vent), SF4.5VF (Secure Flex) firestop/spacer must be used anytime vent pipe passes through a combustible floor or ceiling. SV4.5HF (Secure Vent), SF4.5HF (Secure Flex) firestop/spacer must be used anytime vent pipe passes through a combustible wall.
- Two 45 degree elbows may be used in place of one 90 degree elbow. The same rise to run ratios, as shown in the venting Figures for 90 elbows, must be followed if 45 degree elbows are used.
- AN ELBOW IS ACCEPTABLE AS 1 FOOT OF VERTICAL RISE EXCEPT WHERE AN ELBOW IS THE ONLY VERTICAL COMPONENT IN THE SYSTEM (See Figure 29).

WARNING

Under no circumstances, may separate sections of concentric flexible vent pipe be joined together.





 When using Secure Flex, use Firestop / Spacer SF4.5VF.
 When using Secure Flex, use Firestop / Spacer SF4.5HF.

Figure 24 - Top Vent - TWO 90 DEGREE ELBOWS

Table A			
H Ma	H Maximum		inimum
feet	(meter)	feet	(meter)
5	(1.524)	Elbow Only	
5	(1.524)	1 (0.305	
10	(3.048)) 2 (0.61	
15	(4.572)	3	(0.914)
20	(6.096)	4 (1.219)	
V + V ₁ + H = 40 feet (12.2 m) Max. H = 20 feet (6.096 meters) Max.			

Example: If 20 feet of (H) horizontal vent run is needed, then 4 feet minimum of (V) vertical vent will be required.

This table shows a 1(V) to 5(H) ratio. For every 1 foot of (V) vertical, you are allowed 5 feet of (H) horizontal run, up to a maximum horizontal run of 20 feet.

An elbow is acceptable as 1 foot of vertical rise except where an elbow is the only vertical component in the system. See **Figure 29**.

VERTICAL VENT FIGURES/TABLES (CONTINUED)

Table B				
H + H	₁ Maximum	VN	Ainimum	
feet	(meter)	feet	(meter)	
5	(1.524)	Elb	ow Only	
5	(1.524)	1 (0.305		
10	(3.048)	2	(0.610)	
15	(4.572)	3	(0.914)	
20	(6.096) 4 (1.219)			
	H + H ₁ = 20 fee + V ₁ + H + H ₁ = 4			

Example: If 20 feet total (H+H₁) horizontal vent run is needed, then 4 feet minimum of (V) vertical vent will be required.

This table shows a 1(V) to 5(H) ratio. For every 1 foot of (V) vertical, you are allowed 5 feet of $(H+H_1)$ horizontal run up to a maximum total horizontal run of 20 feet.

An elbow is acceptable as 1 foot of vertical rise except where an elbow is the only vertical component in the system. See Figure 29.



• When using Secure Flex, use Firestop / Spacer SF4.5VF • When using Secure Flex, use Firestop / Spacer SF4.5HF

Figure 25 - Top Vent - THREE ELBOWS

HORIZONTAL (OUTSIDE WALL) TERMINATION SYSTEM

Figure 26 on Page 18, and Figures 27 to 32 on Pages 19 through 22 and their associated Horizontal Vent Table which illustrate the various horizontal venting configurations that are possible for use with these appliances. Secure Vent[™] pipe applications are shown in these Figures; Secure Flex[™] pipe may also be used. A Horizontal Vent Table summarizes each system's minimum and maximum vertical and horizontal length values that can be used to design and install the vent components in a variety of applications.

Both of these horizontal vent systems terminate through an outside wall. Building Codes limit or prohibit terminating in specific areas. Refer to *Figure 6* on *Page 7* for location guidelines. Secure Vent SV4.5 direct-vent system components are unitized concentric pipe components featuring positive twist lock connection, (*refer* to *Figure 17* on *Page 14*). All of the appliances covered in this document are fitted with collars having locking inclined channels. The dimpled end of the vent components fit over the appliance collar to create the positive twist lock connection.

A. Plan the vent run -

Analyze the vent routing and determine the types and quantities of sections required 4-1/2" (114 mm), 10-1/2" (267 mm), 22-1/2" (572 mm), 34-1/2" (876 mm) and 46-1/2" (1181 mm) net section lengths are available. It is recommended that you plan the vent lengths so that a joint does not occur at the intersection of ceiling or roof joists. Make allowances for elbows as indicated in *Figure 19 on Page 15*.

Maintain a minimum 1" (25 mm) clearance to combustibles on the vertical sections. Clearances for the horizontal runs are; 3" (76 mm) on top, 1" (25 mm) on sides, and 1" (25 mm) at the bottom.

B. Frame exterior wall opening -

Locate the center of the vent outlet on the exterior wall according to the dimensions shown in *Figure 11* on *Page 10*. Cut and/or frame an opening, $10-1/2^{"} \times 12-1/8^{"}$ (267 mm x 308 mm) inside dimensions, about this center.

C. Frame ceiling opening - If the vertical route is to penetrate a ceiling, use plumb line to locate the center above the appliance. Cut and/or frame an opening, 10-1/2" x 10-1/2" (267 mm x 267 mm) inside dimensions, about this center (refer to *Figure 16* on *Page 14*).



D. Attach vent components to appliance - To attach a vent component to the appliance collar, align the dimpled end over the collar, adjusting the radial alignment until the four locking dimples are aligned with the inlets of the four incline channels on the collar (*see Figure 17* on *Page 14*).

Push the vent component against the collar until it fully engages, then twist the component clockwise, running the dimples down and along the incline channels until they seat at the end of the channels.

The unitized design of the Secure Vent components will engage and seal both the inner and outer pipe elements with the same procedure. Sealant and securing screws are not required.

Note: An elbow may also be attached to the appliance collar. Attach in the same manner as you would a vent section.

E. Attach vent components to each other - Other vent sections may be added to the previously installed section in accordance with the requirements of the vent tables. To add another vent component to a length of vent run, align the dimpled end of the component over the inclined channel end of the previously installed section, adjusting the radial alignment until the four locking dimples are aligned with the inlets of the four incline channels of the previous section. Push the vent component against the previous section until it fully engages, then twist the component clockwise running the dimples down and along the incline channels until they seat at the end of the channels. This seating position is indicated by the alignment of the arrow and dimple as shown in *Figure 17* on *Page 14*.

F. Install firestop/spacer at ceiling -

When using Secure Vent, use SV4.5VF firestop/ spacer at ceiling joists; when using Secure Flex, use SF4.5VF firestop/spacer. If there is living space above the ceiling level, the firestop/spacer must be installed on the bottom side of the ceiling. If attic space is above the ceiling, the firestop/spacer must be installed on the top side of the joist. Route the vent sections through the framed opening and secure the firestop/spacer with 8d nails or other appropriate fasteners at each corner.

Remember to maintain 1" (25 mm) clearance to combustibles, framing members, and attic or ceiling insulation when running vertical chimney sections. Attic insulation shield (H3907) may be used to obtain the required clearances indicated here. See installation accessories Tables on *Pages 34 and 35*.

G. Support the vertical run sections -See *Section E* on *Page 14.*

H. Change vent direction - At transition from or to a horizontal/inclined run, install the SV4.5E45 and SV4.5E90 elbows in the same manner as the straight vent sections.

The elbows feature a twist section to allow them to be routed about the center axis of their initial collar section to align with the required direction of the next vent run element. **Twist elbow sections in a clockwise direction only so as to avoid the possibility of unlocking any of the previously connected vent sections (see** *Figure 17 on Page 14*).

I. Continue installation of horizontal/inclined sections - Continue with the installation of the straight vent sections in horizontal/inclined run as described in **Step E**. Install support straps every 5 ft. (1.52 m) along horizontal/inclined vent runs using conventional plumber's tape.

See Figure 26. It is very important that the horizontal/inclined run be maintained in a straight (no dips) and recommended to be in a slightly elevated plane, in a direction away from the fireplace of 1/4" rise per foot (20 mm per meter) which is ideal, though rise per foot run ratios that are smaller are acceptable all the way down to at or near level.

It is important to maintain the required clearances to combustibles: 1" (25 mm) at all sides for all vertical runs; and 3" (76 mm) at the top, 1" (25 mm) at sides, and 1" (25 mm) at the bottom for all horizontal/inclined runs.

Use a carpenters level to measure from a constant surface and adjust the support straps as necessary.

J. Assemble vent run to exterior wall - If not previously measured, locate the center of the vent at the exterior wall. Prepare an opening as described in *Step B*. Assemble the vent system to point where the terminus of the last section is located relative to the exterior surface to which the termination is to be attached as shown in *Figure 28 and Table 8*.

If the terminus of the last section is not within this distance, use the **telescopic vent section SV4.5LA**, as the last vent section. For wall thicknesses greater than that shown in *Figure 28*, refer to *Table 8* on *Page 20*. This Table lists the additional venting components needed (in addition to the termination and adapter) for a particular range of wall thicknesses.

K. Attach termination adapter - Attach the adapter (adapter - SV4.5RCH - provided with the termination) to the vent section or telescoping vent section), elbow or appliance collar as shown in *Figure 27* in the same manner as any SV4.5 vent component (refer to *Step E*).

L. Install Firestop/Spacer at exterior wall -When using the termination, install SV4.5HF (Secure VentTM), SF4.5HF (Secure FlexTM) Firestop/Spacer over the opening at the exterior side of the framing, long side up, with the 3 inch spacer clearance at the top as shown in *Figure 27*, and nail into place.

(The Firestop/Spacer may also be installed over the opening at the interior side of framing).

M. Install the Termination (SV4.5HT-2 or SV4.5HTSS)

For the last step, from outside the exterior wall, slide the collars of the termination onto the adapter (the outer inside the outer and the inner outside the inner) until the termination seats against the exterior wall surface to which it will be attached. Orient the housing of the termination with the arrow pointed upwards. Secure the termination to the exterior wall. The horizontal termination must not be recessed into the exterior wall or siding by more than the 1-1/4" (32 mm) as shown in *Figure 28*.

IMPORTANT: The vent termination is hot while in operation and for a period of time following the use of the fireplace. Young children should be carefully supervised when they are in the same area as a hot termination. To prevent contact with hot surfaces, we recommend the use of a *Termination Guard*. See *Page 34*. This can be purchased at your local dealer.





Horizontal terminations have been designed to perform in a wide range of weather conditions. Our terminations meet or exceed industry standards.

When selecting the locations of your horizontal terminations, do not place the termination where water from eaves and adjoining rooflines may create a heavy flow of cascading water onto the termination cap. If the cap must be placed where the possibility of cascading water exists, it is the responsibility of the builder to direct the water away from the termination cap by using gutters or other means.

Take care to carefully follow the installation instructions for the termination, including the use of silicone caulking where required.

Use Table 8 as an aid in venting component selection for a particular range of exterior wall thicknesses.

Venting Components Required for Various Exterior Wall Thick- nesses, when using Typical Termination Kits			
Vent Components Required	Exterior Wall Thickness - inches (mm)		
Termination Kit Only	6 to 9-1/4 (152 to 235)		
Termination Kit and 6 In. Vent Section (SV4.5L6)	10-3/4 to 14 (273 to 356)		
Termination Kit and 12 in. Vent Section (SV4.5L12)	16-3/4 to 20 (426 to 508)		
Termination Kit and Tele- scopic Section (SV4.5L12)	11-3/4 to 20 (299 to 508)		
	Note: See Figure 28 on Page 19 showing wall thickness range when using SV4.5HT-2 termination kit.		

HORIZONTAL VENT FIGURES/TABLES

Notes:

- Secure Vent[™] components (rigid vent pipe and terminal) are shown in the Figures; Secure Flex[™] components (flexible vent pipe and terminal) may also be used.
- Two 45 degree elbows may be used in place of one 90 degree elbow. The same rise to run ratios, as shown in the venting Figures for 90 elbows, must be followed if 45 degree elbows are used.
- SV4.5VF (Secure Vent), SF4.5VF (Secure Flex) firestop/spacer must be used anytime vent pipe passes through a combustible floor or ceiling. SV4.5HF (Secure Vent), SF4.5HF (Secure Flex) firestop/spacer must be used anytime vent pipe passes through a combustible wall.
- It is very important that the horizontal/inclined run be maintained in a straight (no dips) and recommended to be in a slightly elevated plane, in a direction away from the fireplace of 1/4" rise per foot (20 mm per meter) which is ideal, though rise per foot run ratios that are smaller are acceptable all the way down to at or near level.
- The tables show a 1(V) to 5(H) ratio up to a maximum horizontal run of 20 feet except for installations where an elbow is the only vertical vent section in the system (see **Figure 29**).
- AN ELBOW IS ACCEPTABLE AS 1 FOOT OF VERTICAL RISE EXCEPT WHERE AN ELBOW IS THE ONLY VERTICAL COMPONENT IN THE SYSTEM. See Figure 29.

A WARNING

Under no circumstances, may separate sections of concentric flexible vent pipe be joined together.

See Table 8 on Page 20 as an aid in venting component selection for a particular range of exterior wall thicknesses.

Figure 29 - Top Vent -ONE 90 DEGREE ELBOW - ELBOW CONNECTION AT APPLIANCE

Table D			
H Maximum		V Minimum	
feet	(meter)	feet	(meter)
5	(1.524)	1	(0.305)
10	(3.048)	2	(0.610)
15	(4.572)	3	(0.914)
20	(6.096)	4	(1.219)
V + H = 40 feet (12.2 m) Max. H = 20 ft. (6.096 m) Max.			

Example: If 20 feet of (H) horizontal vent run is needed, then 4 feet minimum of (V) vertical vent will be required.

This table shows a 1(V) to 5(H) ratio. For every 1 foot of vertical, you are allowed 5 feet of (H) horizontal run up to a maximum (H) horizontal run of 20 feet.



See Table 8 on Page 20 as an aid in venting component selection for a particular range of exterior wall thicknesses.

Figure 30 - Top Vent - ONE 90 DEGREE ELBOW -ELBOW CONNECTION NOT DIRECTLY AT APPLIANCE

HORIZONTAL VENT FIGURES / TABLES (CONTINUED)



See Table 8 on Page 20 as an aid in venting component selection for a particular range of exterior wall thicknesses.

Figure 31 - Top Vent - TWO 90 DEGREE ELBOWS

	Table E			
H+	H + H ₁ Maximum		linimum	
feet	(meter)	feet	(meter)	
3	(0.914)	Elbow Only		
5	(1.524)	1 (0.305		
10	(3.048)	3.048) 2 (0.6		
15	(4.572)	3	(0.914)	
20	(6.096) 4 (1.219)			
V	V + H + H ₁ = 40 feet (12.2 m) Max. H + H ₁ = 20 ft. (6.096 m) Max.			

Example: If 20 feet of $(H + H_1)$ horizontal vent run is needed, then 4 feet minimum of (V) vertical vent will be required.

This table shows a 1(V) to 5(H) ratio. For every 1 foot of (V) vertical, you are allowed 5 feet of $(H+H_1)$ horizontal run, up to a maximum horizontal run of 20 feet.

An elbow is acceptable as 1 foot of vertical rise except where an elbow is the only vertical component in the system. See **Figure 29**.

HORIZONTAL VENT FIGURES / TABLES (CONTINUED)



Table F				
H + H ₁ Maximum		V	Vinimum	
feet	(meter)	feet	(meter)	
5	(1.524)	Elbow Only		
5	(1.524)	1 (0.305)		
10	(3.048)	2	(0.610)	
15	(4.572)	3	(0.914)	
20	(6.096) 4 (1.219)			
$H + H_1 = 20$ feet (6.096 m) Max. V + V ₁ + H + H ₁ = 40 ft. (12.2 m) Max.				

Example: If 20 feet total $(H+H_1)$ horizontal vent run is needed, then 4 feet minimum of (V) vertical vent will be required.

This table shows a 1(V) to 5(H) ratio. For every 1 foot of (V) vertical, you are allowed 5 feet of (H+ H_1) horizontal run, up to a maximum horizontal run of 20 feet.

An elbow is acceptable as 1 foot of vertical rise except where an elbow is the only vertical component in the system. See **Figure 29**.

Figure 32 - Top Vent - THREE 90 DEGREE ELBOWS

VERTICAL OR HORIZONTAL VENTING USING SECURE FLEX™ KITS AND COMPONENTS

Secure Flex[™] venting kits and components may be used in any venting application in place of rigid Secure Vent[™] (SV4.5) direct-vent components. All restrictions, clearances and allowances that pertain to the rigid piping apply to the flexible venting. Secure Flex kits may not be modified; also, under no circumstances may separate sections of flex pipe be joined together.

Using adapter (SV4.5RF), **Secure Flex** kits may be added to the end of a vent run made up of rigid **Secure Vent** (SV4.5) vent sections provided that doing so does not violate any of the venting length, height, routing, horizontal to vertical ratio requirements or clearance considerations detailed in this manual.

Secure Flex kits come with an adapter that can be fitted to the inclined channel end of the last Secure Vent (SV4.5) vent section in a rigid system in the exact same fashion as any other Secure Vent section. Align the dimpled end of the adapter over the previously installed section or appliance collar, adjusting the radial alignment until the four locking dimples of the adapter are aligned with the inlets of the four incline channels of the last vent section or collar. Push on the adapter until it fully engages, then twist the adapter clockwise running the dimples down and along the incline channels until they seat at the end of the channels.

Attach the flexible vent to the adapter as follows (see also Figure 33):

A. Install the Inner Flex Pipe -

- Install the small gear clamp loosely around the inner flexible vent pipe, push it back out of the way.
- 2. Apply a bead of Mill-Pac Black (700° F) high temperature sealant - Catalog No. 10K81 to the inner adapter collar, approximately 1/2 inch from the end.
- 3. Pull and extend the inner flexible vent pipe.
- 4. Slide the inner flex pipe over the adapter collar. Ensure the flexible vent pipe completely engages the adapter collar to a distance of 1 3/4 inches from the end, and that it is free from damage or tears.
- 5. Slide the gear clamp down and tighten it fully to secure the flexible vent to the adapter inner collar approximately 3/4 inch from the end of the flex.
- Install three screws, 120 degrees apart, through the flexible vent pipe and into the adapter collar just below the gear clamp to provide additional security to the connection.



B. Install the Outer Flex Pipe -

- **1.** Install the large gear clamp loosely around the outer flexible vent pipe, push it back out of the way.
- Apply a bead of Mill-Pac Black (700° F, high temperature sealant - Catalog No. 10K81) to the outer adapter collar; to the grooves of the collar which extend approximately 1 inch from the end and to the flat surface, approximately 1-3/8 inches from the end.
- 3. Pull and extend outer flexible vent pipe.
- 4. Slide the outer flex pipe over the adapter collar. Ensure the flexible vent pipe completely engages the adapter collar to a distance of 1-3/8 inches from the end, and that it is free from damage or tears.
- 5. Slide the gear clamp down and tighten it fully to secure the flexible vent to the adapter outer collar approximately 3/4 inch from the end of the flex.
- 6. Install three screws, 120 degrees apart, through the flexible vent pipe and into the adapter collar just below the gear clamp to provide additional security to the connection.

C. Route Flex Vent -

Ensure that the flex vent is properly routed to provide the required clearance. **Do not** allow the flexible vent to bend in a radius tighter than 5" (127 mm). Refer to *Figure 34*. Space out the internal flex vent spacers evenly - approximately every 6 inches - and avoid kinking of inner pipe. Support horizontal sections of flex with metal straps at 2 foot (0.61 m) intervals.

D. Install Firestop / Spacers at ceilings and walls

- When Secure Flex penetrates a wall or ceiling, a firestop / spacer is required: use the SF4.5 VF firestop / spacer for ceilings and the SF4.5 HF firestop / spacer for walls. See the appropriate sections and Figures shown throughout the venting section for their installation requirements.



E. Attach Flex Vent to Termination -

Secure Flex components can be purchased separately and attached to bulk lengths of Secure Flex flexible tubing cut to size at the job site. Secure the flexible vent to the Secure Flex terminations in the same manner (see Figure 33) as it was attached to the adapter.

Note: Secure Flex vent must be attached to Secure Flex terminations only. DO NOT substitute Secure Vent terminations or the Secure Vent adapter for Secure Flex components. The collars of Secure Flex terminations and adapters have a different diameter than that used with the Secure Vent pipe. Additionally, Secure Flex components have an extended length center tube for use in attaching the flexible vent.

Step 4. FIELD WIRING

A CAUTION

Ground supply lead must be connected to the wire attached to the green ground screw located on the outlet box. See *Figure 37*. Failure to do so will result in a potential safety hazard. The appliance must be electrically grounded in accordance with local codes or, in the absence of local codes, the National Electrical Code, ANSI/NFPA 70-latest edition. (In Canada, the current CSA C22-1 Canadian Electrical Code).

CAUTION: Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation.

ATTENTION: Au moment de l'entretien des commandes, étiquetez tous les fils avant de les débrancher. Des erreurs de cáblage peuvent entraîner un fonctionnement inadéquat et dangereux.

Verify proper operation after servicing.

S'assurer que l'appareil fonctionne adéquatement une fois l'entretien terminé.



Refer to Section A for millivolt appliances and Section B for electronic appliances. The gas valve is set in place and pre-wired at the factory on both models.

A. Millivolt Wiring (See Figure 35) -

- An optional wall-mounted switch, unit mounted rocker switch, wall thermostat, or one of the optional remote control kits may used with this appliance.
- 2. Wire the control switch within the millivolt control circuit using the 15 feet of 2 conductor wire supplied with the unit.

Note: The supplied 15 feet of 2 conductor wire has one end of each conductor connected to the gas valve circuit and the other end of each conductor placed loose inside the bottom compartment.

 If an optional control switch is installed, turn the appliance-mounted ON/OFF burner control switch to the OFF position (if installed).

CAUTION: Do Not connect the optional wall switch to a 120V power supply.

B. Electronic Wiring (See Figure 36) -

Note: The electronic appliance must be connected to the main power supply.

- **1**. Route a 3-wire 120Vac 60Hz 1ph power supply to the appliance junction box.
- 2. Remove the electrical inlet cover plate from the side of the unit by removing the plate's securing screws. *See Figure 11* on *Page 10.*

- **3.** Remove the cover plate's knockout and then feed the power supply wire through the knockout opening and into the unit junction box.
- Connect the black power supply wire to the lower outlet's red pigtail lead and the white power supply wire to the common terminal of the outlet as shown in *Figure 36*.
- Connect the ground supply wire to the pigtail lead attached to outlet's green ground screw.
- 6. Either wall-mounted switch, unit mounted rocker switch (FRS), thermostat, or one of the optional remote control kits is to be used. Mount wall switch or thermostat in a convenient location on a wall near the fireplace.

Note: Remote receiver should be located in the wall, or if installed in the control compartment, pulled all the way forward and completely to the left or right against the corner posts. The door must be removed first to place the receiver in the lower control compartment.

7. If an optional control is to be used, wire it in the low voltage circuit as shown in *Figure 36.*

Note: The supplied 15 feet of 2 conductor wire has one end of each conductor connected to the gas valve circuit and the other end of each conductor placed loose inside the bottom compartment.

- If the optional unit mounted ON/OFF (FRS) control switch is installed, turn the ON/OFF switch to the OFF position.
- **9.** After the wiring is complete, replace the cover plate.



NOTE: DIAGRAMS & ILLUSTRATIONS ARE NOT TO SCALE.

Note: No batteries to be installed in the battery holder until a power outage, or if the appliance is to be operated solely with two (2) "D" batteries.



Step 5. WIRING - OPTIONAL FORCED AIR BLOWER KIT

Blower Access

Blower access is through the firebox bottom. Remove the front panel, the porcelain panels, the sub-floor, remove the burner and remove ten screws securing the GTA assembly to the firebox.

An electrical outlet box is provided for the installation of the **FBK-100 and FBK-200** forced air blower kit. Electrical power must be provided to this box to operate these blowers. Install the blower kit according to the installation instructions provided with the kit.

Reposition and reinstall the GTA assembly, burner and sub-floor.

Step 6. CONNECTING GAS LINE

All codes require a shut-off valve mounted in the supply line. The orientation of the shut-off valve should face the front. *Figure 38* illustrates two methods for connecting the gas supply. A Sediment Trap is recommended to prevent moisture and debris in gas line from damaging the valve.

The flex-line method is acceptable in the U.S.A. where local codes permit, however, Canadian requirements vary depending on locality. Installation must be in compliance with local codes. These appliances are equipped with a gas flex-line for use in connecting the unit to the gas line. See *Figure 38* for flex-line description. The flex-line is rated for both natural and propane gas. A manual shut off valve is also provided with the flex-line.

The gas control valve is located in the lower control compartment.

Access the valve compartment by removing the lower control compartment panel (*see Figure 39)* by sliding and pulling the panel forward. The panel is mounted at the extreme right and left hand sides, through slots. Engage the tabs into the slots in the panel.

The millivolt and electronic control valve has a 3/8" (10 mm) NPT thread inlet port.

Secure all joints tightly using appropriate tools and sealing compounds (ensure propane resistant compounds are used in propane applications). It is recommended to seal around the gas line to prevent cold air leakage.

Gas line connection may be performed largely outside of the confines of the control compartment and without having to enter the firebox behind the glass. Proceed as follows:

Acquire the shut-off valve and gas lex line and pull the assembly forward out of the compartment. Separate the shut-off valve from the gas flex-line. Determine the length of pipe needed to route the gas line from the last fitting (shown in *Figure 13* on *Page 11*) to a point within the control compartment that will allow the shutoff valve to be easily attached by hand to the gas flex-line.

Using pipe-dressing materials appropriate for the gas type, securely affix the shut-off valve to this determined pipe length at a convenient location **<u>outside</u>** of the appliance lower control compartment.





Refer to *Figure 40* and insert the last length of gas pipe with its attached shut-off valve into the lower control compartment and pass it through the gas line access hole on the left side of the appliance outer wrapper. Using appropriate materials for the gas type, thread the last length of pipe into the end of the gas vent run and tighten in place using a pipe wrench *external* to the appliance *between* the appliance outer wrapper and the framing.

Important: Turn the last piece of gas pipe in the last fitting until the shut-off valve is positioned in a way that allows the shut-off valve handle to be accessed in the lower control compartment, easily operated throughout its full range of motion.

Bring the flex-line to the shutoff valve by hand and align the flare fittings. Tighten the fittings by hand, and then use an open end wrench to tighten completely, 1/4 turn at a time.



Figure 40

Length Of Pipe With Attached Shut-Off Valve

TEST ALL CONNECTIONS FOR GAS LEAKS (FACTORY AND FIELD):

WARNING

Never use an open flame to check for leaks.

Turn on gas supply and test for gas leaks, using a gas leak test solution (also referred to as bubble leak solution).

Note: Using a soapy water solution is an effective leak test solution but it is not recommended, because the soap residue that is left on the pipes/fittings can result in corrosion over time. **Never use an open flame to check for leaks.**

- **A.** Light the appliance (refer to the lighting instructions label in the control compartment or in the Care and Operation Instructions manual).
- B. Brush all joints and connections with the gas leak test solution to check for leaks. If bubbles are formed, or gas odor is detected, turn the gas control knob to the "OFF" position. Either tighten or refasten the leaking connection and retest as described above.
- **C.** When the gas lines are tested and leak free, be sure to rinse off the leak testing solution.

Step 7. VERIFYING APPLIANCE OPERATION

Turn on burner then observe the individual tongues of flame on the burner. Make sure all ports are open and producing flame evenly across the burner. If any ports are blocked, or partially blocked, clean out the ports.

With gas line installed run initial system checkout before closing up the front of the unit. Follow the pilot lighting instructions provided in the Care and Operation Instructions. For piezo igniter location see *Figure 39 on Page 26* (millivolt appliances only).

Note: Lighting Instructions are also found on the literature tag tied to the gas piping next to the gas valve. To access the tag, open the lower control compartment door (**Figure 39 on Page 26**) by pulling the panel forward.

When first lighting the appliance, it will take a few minutes for the line to purge itself of air. Once purging is complete, the pilot and burner will light and operate as indicated in the instruction manual. Subsequent lighting of the appliance will not require such purging. Inspect the pilot flame (remove contemporary floor media, if necessary, handling carefully).

Millivolt Appliance Checkout

The pilot flame should be steady, not lifting or floating. Flame should be blue in color with traces of orange at the outer edge.

The top 3/8" (10 mm) at the pilot generator (thermopile) and the top 1/8" minimum (tip) of the quick drop out thermocouple should be engulfed in the pilot flame.

The flame should project 1" (25 mm) beyond the hood at all three ports (see *Figure 41*). Replace contemporary floor media if removed for pilot inspection.

To light the burner; turn "ON" the remote wall switch and rotate the gas valve control knob counterclockwise to the "ON" position ("ON" will be at the top side of the valve).



Electronic Appliance Checkout

To light the burner, turn 'ON' the unit mounted On/Off switch or the optional remote wall switch. Ensure the igniter lights the pilot. The pilot flame should engulf the flame rod as shown in *Figure 42*.



Step 8. INSTALLING CONTEMPORARY MEDIA

NOTE: Turn off all electricity to the appliance before you install contemporary floor media.

A WARNING

- DO NOT attempt to install the contemporary media until the appliance installation has been completed, the gas line connected and tested for leaks and the initial burner operation has been checked out.
- The size and position of the contemporary media was engineered to give the appliance a safe, reliable and attractive flame pattern. Any attempt to use a different media in the fireplace will void the warranty and will result in incomplete combustion, sooting, and poor flame quality.
- Contemporary media get very hot and will remain hot up to one hour after gas supply is turned off. Handle only when contemporary media are cool.
- This appliance is not designed to burn wood. Any attempt to do so could cause irreparable damage to the appliance and prove hazardous to your safety.
- If contemporary media are not installed according to the installation instructions, flame impingement and improper combustion could occur and result in soot and/or excessive production of carbon monoxide (CO), a colorless, odorless, toxic gas.
- Only use materials listed here. Only contemporary media authorized have been tested for use within the firebox and its environment. Do not attempt to use any different materials in the fireplace. Doing so may be dangerous and will void the warranty and will result in incomplete combustion, sooting, and poor flame quality.

Table Of Contemporary Media			
Cat. No.	Model	Contemporary Media Name	
H7536	MTRS	Tumbled River Stone	
H7537	MCCG-OB	Contemporary Glass Obsidian Black	
H7538	MBSK	Contemporary Beach Sand	
H7578	MCCG-DW	Contemporary Glass Diamond White	
H7579	MCCG-SB	Contemporary Glass Deep Sea Blue	
H7581	MBLPK-35ZG	Merit Liner Kit, Zen Garden	

Remove the front glass enclosure panel (see *Removing Glass Enclosure Panels* on *Page 30*).

This fireplace is designed to accept a number of alternate contemporary media options, allowing the homeowner to customize this product to fit any decor.

Install Zen Garden Refractory Panels (MBLPK-35ZG) -

- **1.** Porcelain panels come installed in the appliance. Remove them by bending the tab, sliding the left and right side panels out first, then removing the rear panel.
- 2. Install Zen Garden panels:
- Remove the lintel by removing two screws.
- Insert the rear panel into firebox and position against the rear wall of the firebox (see Figure 43 - Detail A on Page 29).
- Carefully insert the left side panel into firebox, at a slight angle away from the sidewall. Position the side panel as far back along the wall as it will go (until it is against the rear panel) and lower it into place, while standing it upright and pressing it down over the knife edge at the rear of the sub-floor. The sub-floor knife edge will cut into the refractory panel. Repeat the same procedure for the right side panel (see Figure 43 - Detail B on Page 29).
- Re-install the lintel.

Install Tumbled River Stone (MTRS) -

IMPORTANT: Refractory panels should be installed before any of the contemporary media are installed.

 Place stones on the firebox sub-floor, in any atheistically pleasing manner to suite individual taste. See *Figure 43 - Detail C on Page 29* for an example.

IMPORTANT: Be sure stones do not impinge on the burner outlet.

Install Crushed Glass And Sand (MCCG and MBSK) -

IMPORTANT: Refractory panels should be installed before any of the contemporary media are installed.

 Pour out glass or sand on firebox subfloor, completely covering the sub-floor. See *Figure 43 - Detail D on Page 29* for an example.

IMPORTANT: Avoid letting glass or sand fall into the burner outlet. Make sure no glass or sand falls into the burner ports.

Install Contemporary Facade -

1. Refer to the Facade Installation Instructions (P/N 506019-40) to install the Contemporary Facade.



Step 9. INSTALLATION AND REMOVAL OF GLASS DOOR

A WARNING

- Do not attempt to substitute the materials used on these doors, or replace cracked or broken glass.
- Handle this glass with extreme care! Glass is susceptible to damage – Do not scratch or handle roughly while reinstalling the glass door frame.
- The glass door(s) of this appliance must only be replaced as a complete unit as provided by the manufacturer. Do not attempt to replace broken, cracked or chipped glass separately.
- Do not attempt to touch the front enclosure glass with your hands while the fireplace is in use.

🛕 WARNING

Do not operate appliance with the glass front removed, cracked or broken.

AVERTISSEMENT

Ne pas utiliser l'appareil si le panneau frontal en verre n'est pas en place, est craqué ou brisé.

Only doors certified with the appliance shall be used.

Seules des portes certifiées pour cet appareil doivent être utilisées.

CAUTION: DO NOT abuse glass door by striking or slamming shut.

Removing Glass Enclosure Panels (see *Figure 44*)

- To access the glass door securing latches, first open the lower control compartment door (*Figure 44*) by sliding and pulling the bottom panel forward.
- 2. Pull the latches forward and down to release them from the door channel.

- **3.** Pull the bottom of the door out a few inches and grasp it on the right and left. Gently lift to release the door from its channel above the door. Pull the door forward.
- **4.** Retrieve the glass door. Visually inspect the gasket on the backside of the frame. Gasket surface must be clean, free of irregularities and seated firmly.
- Inspect the gasket for defects. Ensure it is properly located. Make sure the bead is not rolled up into the channel at the top of the door, but remains flat against the top of the glass (see *Figure 44*).
- 6. Position the door in front of the firebox opening with the bottom of the door held away from the fireplace (*Figure 44*). Hook the top flange of the door frame over the top of the firebox frame.
- 7. Let the bottom of the door frame swing gently in towards the fireplace ensuring that the gasket seats evenly as the door frame draws shut. Fasten the two latches located underneath the firebox floor to the door's veeflange. Close both the latches securely.
- 8. Install the hood. Note the location of the three clips inside the top air channel above the door. The clips are equally spaced on the top surface of the air channel opening. Use a screwdriver to open the clips slightly if needed. Engage the back edge of the eyebrow into the clips to secure.



Note: When installing the glass door, ensure the spacing on both sides are equal.

Figure 44 -INSTALLING OR REMOVING GLASS DOOR

Step 10. BURNER ADJUSTMENTS

Flame Appearance and sooting

Proper flame appearance is a flame which is blue at the base and becomes yellowish-orange in the body of the flame.

When the appliance is first lit, the entire flame may be blue and will gradually turn yellowishorange during the first 15 minutes of operation. After 15 minutes of operation, if the flame is blue, or if the flame is orange with evidence of sooting (black tip), the air shutter opening may need to be adjusted.

If the air shutter openings is closed too far, sooting may develop. Sooting is indicated by black puffs developing at the tips of very long orange flames. Sooting results in black deposits forming on the appliance inside surfaces and on exterior surfaces adjacent to the vent termination.

Sooting is caused by incomplete combustion in the flames and lack of combustion air entering the air shutter opening. To achieve a warm yellowish-orange flame with an orange body that does not soot, the shutter opening must be adjusted between these two extremes.

Air Shutter Adjustment Guidelines

- If there is smoke or soot present, the air shutter opening should be increased.
- The more offsets in the vent system, the larger the air shutter opening will need to be.
- An appliance operated with the air shutter opened too far, may have flames that appear blue and transparent. These weak, blue and transparent flames are termed anemic.
- Propane models may exhibit flames which candle or appear stringy. If this is present and persists, adjust the air shutter to a more closed position, then operate the appliance for a few more minutes to ensure that the flame normalizes and the flames do not appear sooty.

The following chart is provided to aid you in achieving the correct air shutter adjustment for your installation.

Air Shutter Adjustment Guidelines:			
Amount of Primary Air	Flame Color	Air Shutter Adjustment	
If air shutter is closed too far	Flame will be orange	Air shutter gap should be increased	
If air shutter is open too far	Flame will be blue	Air shutter gap should be decreased	

Burner Air Shutter Adjustment Procedure

🛕 WARNINGS

- Air shutter adjustment should only be performed by a qualified professional service technician.
- Ensure front glass panel are in place and sealed during adjustment.

A CAUTIONS

- Soot will be produced if the air shutter is closed too much. Any damage due to carboning resulting from improperly setting the air shutter is not covered under the warranty.
- The air shutter door and nearby appliance surfaces are hot. Exercise caution to avoid injury while adjusting flame appearance.
- Ensure the air shutter setting is at least equivalent to 1/2 of the air hole exposed when operating the unit with propane gas.
- 1. Locate and adjust the air shutter to the standard setting as shown in *Figure 45*.
- Light appliance (follow lighting procedure on lighting label in control compartment or see the Care and Operations manual).
- Allow the burner to operate for at least 15 minutes while observing the flame continuously to ensure that the proper flame appearance has been achieved (see *Figure* 46). If the following conditions are present, adjust accordingly.
 - If flame appears weak or sooty, adjust the air shutter, incrementally, to a more open position until the proper flame appearance is achieved.
 - If flame stays lowered blue, adjust the air shutter, incrementally, to a more closed position until the proper flame appearance is achieved.
- Leave the control knob (off/pilot/on) in the ON position and the burner ON/OFF switch OFF (and remote switches, if applicable).
- **5.** When satisfied that the burner flame appearance is normal, re-install the lower control compartment door then proceed to finish the installation.







(River Stone And Beach Sand With Porcelain Panels Shown)

Figure 46 - Burner Flame Appearance Model MLDVTCD-35

Step 11. HOOD INSTALLATION

(Refer to Figure 47) All of these appliances must have hoods installed prior to operating.

Install hood by sliding it into the slots on the lower edge of the cabinet top.

FINISHING REQUIREMENTS - Wall Details

Complete finished interior wall. To install the appliance facing flush with the finished wall, position framework to accommodate the thickness of the finished wall (*Figure 47*).



See Page 5 for Cold Climate Insulation and Page 8 for Clearances

Figure 47 - Combustible Wall Framing

FINISHING REQUIREMENTS - Contemporary Facade

This contemporary unit is uniquely suited for mid-wall installations with an available self-finishing decorative contemporary Facade. The decorative contemporary Facade is listed in the accessories sections of the Care And Operations manual and consists of three elements that can be mixed and matched for finishes to taste. This appliance, without the decorative contemporary Facade, may be installed on the floor as any traditional fireplace (use the framing dimensions *as-is* as shown in *Figure 11 on Page 10*), but if the decorative contemporary Facade is to be installed, the unit must be raised on a platform at least 18" high (greater than 28" recommended) (*refer to Figure 48*).

Note: When raising the MLDVTCD appliance on a platform for mid-wall installations, add the platform height to any of the framing dimensions shown in **Figure 11 on Page 10** and adjust the gas line dimensions shown in **Figure 13 o Page 11** upwards accordingly.

The decorative contemporary Facade's significant dimensions are shown in *Figure 48*. The decorative contemporary Facade may be installed over drywall that is butted directly against the sides of the fireplace, or noncombustible wall finish materials, no more than 3/4" thick, that are placed in front of the fireplace black painted face. DO NOT place the Facade over combustible materials that are placed in front of the fireplace's black finished face. Refer to the installation instructions that accompany the decorative contemporary Facade for installation details.





Step 12. ATTACHING SAFETY-IN-OPERATION WARNINGS

It is the installers responsibility to ensure these warnings are properly affixed during installation. These warning labels are a critical step in informing consumers of safe operation of this appliance.

Votre foyer a été livré avec des étiquettes de sécurité qui

doivent être collées à côté des dispositifs de contrôle

du foyer. Une étiquette de sécurité doit être collée sur

la plaque de l'interrupteur contrôlant l'allumage du

fover (voir Figure A) ou sur le thermostat mural (voir

Fiqure B) et, le cas échéant, sur le boîtier de la télé-

commande (Figure C). Les mises en garde auraient dû

être collées au moment de l'installation initiale du foyer.

Si ce n'est pas le cas, prenez les étiquettes adhésives

multilingues fournies avec ces instructions et procédez

1. Repérez l'interrupteur ou le thermostat mural

qui contrôle le foyer (vérifiez que l'interrupteur

contrôle le fonctionnement du foyer en le faisant

basculer de Marche à Arrêt, et vice-versa). Nettoyez

soigneusement la plague murale de l'interrupteur

ou le thermostat mural pour éliminer la poussière

et les traces de graisse ou d'huile. Collez l'étiquette

sur la surface de la plaque de l'interrupteur mural

qui contrôle le foyer (Figure A) ou du thermostat

mural (Figure B). Choisissez la langue qui est

principalement parlée dans la résidence du

Si une télécommande est utilisée pour contrôler

le foyer, nettoyez la soigneusement pour éliminer

la poussière et les traces de graisse ou d'huile.

Collez l'étiquette sur le boîtier de la télécommande

(Figure C). Choisissez la langue qui est principale-

Si vous ne trouvez pas les étiquettes, veuillez

appeler Lennox Hearth Products ou votre distribu-

teur Lennox Hearth Products local pour recevoir

ment parlée dans la résidence du propriétaire.

gratuitement des étiquettes supplémentaires.

Étiquettes de remplacement, n° cat. H8024

Remarque : Le texte anglais est rouge sur un support transparent. Le texte français et espagnol est blanc

LENNOX HEARTH PRODUCTS

1-800-9-LENNOX

À LA SÉCURITÉ D'UTILISATION

comme suit:

propriétaire.

2.

3.

ATTACHING SAFETY-IN-OPERATION WARNINGS

Your fireplace has been furnished with safety instruction labels that are to be affixed to the operation and control point of the fireplace. A safety instruction label should be affixed to the wall switch plate where the fireplace is turned on and off (See Figure A) or wall thermostat (See Figure B) and if used on the remote control handheld transmitter (Figure C). The warnings should already have been put in place when the fireplace initial set-up was completed. If they are not affixed at these spots, locate the multi-lingual adhesive labels provided with these instructions and proceed as follows:

- 1. Locate the wall switch or wall thermostat that controls the fireplace (verify the switch operates the fireplace by turning it on and off). Clean the wall switch plate or wall thermostat thoroughly to remove any dust and oils. Affix the label to the surface of the plate of the wall switch that controls the fireplace (Figure A) or the wall thermostat (Figure B). Choose the language primarily spoken in the home.
- 2. If a remote control is used to control the fireplace, locate the transmitter and clean it thoroughly to remove any dust and oils. Affix the label to the surface of handheld transmitter (*Figure C*). Choose the language primarily spoken in the home.
- 3. If you are unable to locate the labels, please call Lennox Hearth Products or your nearest Lennox Hearth Products dealer to receive additional safety instruction labels free of charge.

Cat. No. H8024 Replacement Label Kit

LENNOX HEARTH PRODUCTS 1-800-9-LENNOX

Note: English is red text on clear label. French and Spanish are white text on black label.

sur un support noir. SAFETY LABEL DIAGRAMMES DES ÉTIQUETTES **DE SÉCURITÉ** DIAGRAMS **VERTISSEM** WARNING Vitre et foyer EXTRÊMEMENT CHAUDS EXTREMELY HOT glass and fireplace Risque de brûlures graves Risk of Severe Burns Toujours tenir les enfants á ALWAYS KEEP CHILDREN AWAY FROM FIREPLACE l'écart du foyer ß Figure A Figure B A WARNING A WARNING

APPOSITION DES MISES EN GARDE RELATIVES COLOCACIÓN DE ADVERTENCIAS DE SEGURIDAD EN OPERACIÓN

Su chimenea incluye etiquetas de instrucciones de seguridad que deben colocarse en el punto de operación y control de la chimenea. Se debe colocar una etiqueta de instrucciones de seguridad en la placa del interruptor de pared desde el cual se enciende y se apaga la chimenea (ver la Figura A) o en el termostato de pared (ver la Figura B) y en el transmisor de control remoto (Figura C) si se usa. Las advertencias va deben haberse colocado cuando se completó la instalación inicial de la chimenea. Si no están colocadas en estos lugares, encuentre las etiquetas adhesivas multilingües proporcionadas con estas instrucciones y prosiga de la siguiente manera:

- 1. Identifique el interruptor o el termostato de pared que controla la chimenea (verifique que el interruptor opera la chimenea encendiéndola y apagándola). Limple bien la placa del interruptor o el termostato de pared para quitar el polvo y aceite. Pegue la etiqueta en la superficie de la placa del interruptor que controla la chimenea (Figura A) o en el termostato de pared (Figura B). Seleccione el idioma que más se habla en la casa.
- 2. Si se usa un control remoto para controlar la chimenea, encuentre el transmisor y límpielo bien para guitar el polvo y aceite. Pegue la etigueta en la superficie del transmisor (Figura C). Seleccione el idioma que más se habla en la casa.
- 3. Si no puede encontrar las etiquetas, sírvase llamar a Lennox Hearth Products o al distribuidor de Lennox Hearth Products más cercano para recibir etiquetas de instrucciones de seguridad adicionales gratuitas.

Juego de etiquetas de repuesto - Nº de cat. H8024

LENNOX HEARTH PRODUCTS 1-800-9-LENNOX

Nota: La etiqueta en inglés es transparente con texto roio. Las etiquetas en francés y español son negras con texto blanco.

DIAGRAMAS DE ETIQUETAS DE SEGURIDAD



75.4

Figure C

INSTALLATION ACCESSORIES

	Listed Secure Vent™Components			
	Cat.No.	Model No.	Description	
	H1968	SV4.5HT-2	Horizontal Square Termination with Firestop/Spacer (H2246) and Adapter (74L61)	
Solo and a	94L10	SV4.5HTSS	Horizontal Termination Small Square with Firestop/Spacer (H2246) and Adapter (74L61)	
S.	H5817	SV4.5-20SS- WSK	Small Square Termination, 20" With Shield	
	H2152	SV4.5CGV-1	Vertical Termination (High Wind)	
	77L70	SV4.5L6	6 inch (152 mm) Vent Section	
0	77L71	SV4.5L12	12 inch (305 mm) Vent Section	
	77L72	SV4.5L24	24 inch (610 mm) Vent Section	
	77L73	SV4.5L36	36 inch (914 mm) Vent Section	
	77L74	SV4.5L48	48 inch (1219 mm) Vent Section	
	77L75	SV4.5LA	Telescopic Section (2" to 7.5" Rigid)	
	77L76	SV4.5E45	45 Degree Elbow	
	77L77	SV4.5E90	90 Degree Elbow	

		ent ™Components	
	Cat.No.	Model No.	Description
	77L78	SV4.5F	Flat Roof Flashing
	77L79	SV4.5FA	1/12 to 7/12 Adjustable Flashing
	77L80	SV4.5FB	7/12 to 12/12 Adjustable Flashing
	77L81	SV4.5SC6	Storm Collars (6 collars/box)
1501	H2246	SV4.5HF	Firestop/Spacer - 10 pack Horizontal (3-1-1 spacing)
	H2247	SV4.5VF	Firestop/Spacer - 10 pack Vertical (1-1-1 spacing)
	96K93	SV4.5SU	Support Strap
9	H3907	SV4.5ARSA	Adjustable Attic Insulation Shield (12" to 22")
	H5816	SV4,5TWSK	Through Wall Shield Kit (not illustrated) (10 pack)
	96K92	SV4.5SP	Support Plate
	87L02	SV4.5HGS	Termination Guard Square (not illustrated)
	H5820	4.5HTSK	Horizontal Termination Shroud Kit
	99L03 99L02	SV4.5HRK36 SV4.5HRK14	Horizontal Riser Kit 36" Horizontal Riser Kit 14"

INSTALLATION ACCESSORIES CONTINUED

Listed Secure Flex™Components				
	Cat. No.	Model No.	Description	
These termination	These termination kits include firestop/spacer, gear clamps and flex adapter.			
	H1969	SF4.5HT-2	Horizontal Square	
16			Termination without Flex	
	77L87	SFKIT12	Flex Square Term. with	
			12 in. (305 mm of	
	77L88	SFKIT18	*compressed Flex Flex Square Term. with	
	//L00	SERITO	18 in. (457 mm) of	
			*compressed Flex	
	771 89	SFKIT24	Flex Square Term. with	
	11209	511124	24 in. (610 mm) of	
			*compressed Flex	
(°	77L90	SFKIT36	Flex Square Term. with	
	11230		36 in. (914 mm) of	
			*compressed Flex	
	771 91	SFKIT48	Flex Square Term. with	
			48 in. (1219 mm) of	
			*compressed Flex	
	94L09	SF-HTSS	Horizontal Termination -	
			Small Square for Flex Vent	
LI-TO MA	94L04	SFKIT12SS	Flex Small Termination with	
			12 in. (305mm) Flex Vent	
	94L05	SFKIT18SS	Flex Small Termination with	
			18 in. (457mm) Flex Vent	
	94L06	SFKIT24SS	Flex Small Termination with	
	0.41.07		24 in. (610mm) Flex Vent	
	94L07	SFKIT36SS	Fle in. Small Termination	
			with	
	041.00	SFKIT48SS	36 in. (914mm) Flex Vent Flex Small Termination with	
	94L08	STN114055		
	56L74	SEVT30	48 in. (1219mm) Flex Vent Vertical Termin. for Flex	
	JUL/4	51 7130	(flat to 6/12) with Flex	
			Adapter, section of rigid	
			vent, roof support collar	
			assembly, roof flashing and	
			storm collar.	
	561 75	SEVT45	Vertical Termin. for Flex	
	50275		(6/12 to 12/12) with Flex	
			Adapter section of rigid	
			vent, roof support collar	
			assembly, roof flashing and	
			storm collar.	
			storm conai.	

Listed Coours FloyIMComponents				
Listed Secure Flex™Components				
	No.	Model No.	Description	
	H1988 H1985	CTSA-33 CTSO-33	Chase Top Shroud Kit, Arch Top - 3 X 3 Chase Top Shroud Kit	
	H1985	CTSO-33	Chase Top Shroud Kit, Open Top - 3 X 3 Chase Top Shroud Kit,	
	H1986	CTSO-46	Open Top - 4 X 4 Chase Top Shroud Kit,	
			Open Top - 4 X 6	
	60L10	SF-18	18 ft. (5.49 m) *compressed Flex	
	98K03	SF-12	12 ft.(3.66 m) *compressed Flex	
	10K81	SFMP	Mil Pac Black Hi- Temperature Sealant	
	89L40	SFMP-12	Mil Pac Black Hi- Temperature Sealant - Bulk Pack 12	
~	91L66	SF-GC4-6	Gear Clamp 4.5in. (114 mm) for Flex (6 pieces)	
\bigcirc	91L67	SF-GC7-6	Gear Clamp 7.5 in. (190.5 mm) for Flex (6 pieces)	
	H2248	SF4.5HF-10	Firestop/Spacer - 10 Pack Horizontal (3-1-1 spacing)	
	H2249	SF4.5VF-10	Firestop/Spacer - 10 Pack Vertical (1-1-1 spacing)	

*All compressed flex vents can be expanded up to two times.

GAS CONVERSION KITS

🛕 WARNING

This conversion kit shall be installed by a qualified service agency in accordance with the manufacturer's instructions and all applicable codes and requirements of the authority having jurisdiction. If the information in these instruction is not followed exactly, a fire, explosion or production of carbon monoxide may result causing property damage, personal injury or loss of life. The qualified service agency is responsible for the proper installation of this kit. The installation is not proper and complete until the operation of the converted appliance is checked as specified in the manufacturer's instructions supplied with the kit. The qualified service agency performing this installation assumes responsibility for this conversion.

AVERTISSEMENT

Cette trousse de conversion doit être installée par un technicien agréé, selon les instructions du fabricant et selon toutes les exigences et tous les codes pertinents de l'autorité compétente. Assurez-vous de bien suivre les instructions dans cette notice pour réduire au minimum le risque d'incendie, d'explosion ou la production de monoxyde de carbone pouvant causer des dommages matériels, des blessures ou la mort. Le tecnicien agréé est responsable de l'installation de cette trousse. L'installation n'est pas adéquate ni complète tant que le bon fonctionnement de l'appareil converti n'a pas été vérifié selon les instructions du fabricant fournies avec la trousse. Le fournisseur de service qualifié ayant réalisé l'installation assume les responsabilités liées à la conversion.

In Canada:

THE CONVERSION SHALL BE CAR-RIED OUT IN ACCORDANCE WITH THE REQUIREMENTS OF THE PROVINCIAL AUTHORITIES HAVING JURISDICTION AND IN ACCORDANCE WITH THE RE-QUIREMENTS OF THE CAN/CSA-B149.1 INSTALLATION CODE.

LA CONVERSION DEVRA ÊTRE EF-FECTUÉE CONFORMÉMENT AUX RE-COMMANDATIONS DES AUTORITÉS PROVINCIALES AYANT JURIDICTION ET CONFORMÉMENT AUX EXIGENCES DU CODE D'INSTALLATION CAN/CSA-B149.1.

Gas conversion kits are available to adapt your appliance from the use of one type of gas to the use of another. These kits contain all the necessary components needed to complete the task including labeling that must be affixed to ensure safe operation.

Kit part numbers are listed here and the following steps detail the conversion procedure. Refer to the instructions provided with the conversion kit when performing any gas conversion.

<i>Millivolt</i> SIT Systems Natural Gas To <u>Propane Gas</u> Conversion Kits	
Model	Cat. No.
MLDVTCD-35	H7292

<i>Millivolt</i> SIT Systems Propane to <u>Natural Gas</u> Conversion Kits	
Model	Cat. No.
MLDVTCD-35 H7293	

<i>Electronic</i> DEXEN Systems Natural Gas To <u>Propane Gas</u> Conversion Kits	
Cat. No.	
MLDVTCD-35 H7295	

<i>Electronic</i> DEXEN Systems Propane Gas To <u>Natural Gas</u> Conversion Kits	
Model	Cat. No.
MLDVTCD-35	H7296

INSTALLATION INSTRUCTIONS

Step 1. TURN OFF THE GAS SUPPLY TO THE APPLIANCE, and disconnect power supply at the circuit breaker. Ensure appliance is COLD.

CAUTION: THE GAS SUPPLY SHALL BE SHUT OFF PRIOR TO DISCONNECTING THE ELECTRICAL POWER, BEFORE PROCEEDING WITH THE CONVERSION.

ATTENTION : AVANT D'EFFECTUER LA CONVERSION, COUPEZ D'ABORD L'ALIMENTATION EN GAZ, ENSUITE, COUPEZ L'ALIMENTATION ÉLECTRIQUE.

Step 2. Remove the front glass door assembly. See *Figure 44 on Page 30*.

Step 3. Carefully remove the contemporary floor media. Exercise care so as not to break the contemporary floor media.

Step 4. Refer to Figure 49.

Remove the burner assembly with attached venturi tube.



Millivolt Appliances

Step 5. SIT Systems - Refer to *Figure 50 on Page 37* and the instructions provided with the kit. Using a Torx T20 (with 1/4" shank and center hole), tool or standard flat screwdriver remove and discard the three pressure regulator mounting screws. Remove the pressure regulator, spring, poppet, diaphragm and bushing. **Discard all removed components**.

Ensure the rubber gasket installed on the back of the replacement pressure regulator is properly positioned and install the new pressure regulator using the new screws supplied with the kit. Tighten screws to 25 In. Ib. torque.



Step 6. See *Figure 51* and remove the pilot hood assembly to access the hexed pilot orifice. Remove and replace the orifice with the one provided with the kit.



Electronic Appliances

Step 7. Dexen Electronic Valves - See *Figure 52* and the instructions provided with the kit. Remove and discard the two pressure regulator mounting screws. Remove the pressure regulator and diaphragm. Discard all removed components. Ensure the provided diaphragm is installed properly onto the replacement pressure regulator and install the new pressure regulator using the new screws supplied with the kit. Tighten screws.

See *Figure 53* and replace the pilot orifice as follows: Remove pilot hood assembly to access the phillipped pilot orifice. Remove and replace the orifice with the one provided with the kit. Exercise extreme care to prevent damage to or breakage of the igniter assembly.





Note: If the igniter is damaged, a replacementkit is available, order Catalog Number 87L54.

Figure 53

Step 8. (Refer to *Figure 49 on Page 36 and Figure 54*)

VERIFY THE PROPER ORIFICE SIZE BEFORE INSTALLING IT.

A. Remove the orifice from the manifold and replace it with the one provided in the kit. See *Table 9* for orifice sizes for natural and propane models. *Figure 54* illustrates the orifice. Use pipe joint compound or Teflon tape on all pipe fittings before installing (ensure propane resistant compounds are used in propane applications, do not use pipe joint compounds on flare fittings).

B. Retrieve the burner and slide the venturi tube over the orifice. Set the shutter adjusting opening as shown in *Figure 49 on Page 36*.

Burner Orifice Sizes Elevation 0-4500 feet (0-1372 meters)			
Model Series	Nat.Gas drill size (inches) drill size (inches)		
MLDVTCD-35	#49 (0.073") * 21L82 •	(0.045") ** 75L10 •	
* Standard size installed at factory ** Standard size in LP conversion kit • Part /Cat. Number			



Step 9. Reassemble the remaining components by reversing the procedures outlined in the preceding steps.

Step 10. Attach the conversion label provided in the conversion kit to the rating plate on the appliance.

Step 11. Turn on gas supply and test for gas leaks. See *Test All Connections For Gas Leaks* on *Page 27*.

Step 12. Attach manometer to the manifold side pressure test fitting and verify manifold pressure reads 3.5 inches water column (0.87 kPa) for natural gas, and 10.0 inches water column (2.49 kPa) for propane gas.

ALWAYS TEST PRESSURES WITH THE VALVE REGULATOR CONTROL AT THE HIGHEST SETTING.

Lennox Hearth Products reserves the right to make changes at any time, without notice, in design, materials, specifications, prices and also to discontinue colors, styles and products. Consult your local distributor for fireplace code information.



HEARTH PRODUCTS

Printed in U.S.A. © 2009/2012 Lennox Hearth Products P/N 506015-03 Rev. G 02/2012

1508 Elm Hill Pike, Suite 108 • Nashville, TN 37210