

Operating Instructions for The Vermont Bun Baker

Save These Instructions

Please read this entire manual before you install and use your new room heater. Failure to follow instructions may result in property damage, bodily injury, or even death.

The Vermont Bun Baker is distributed by Vermont Woodstove Company a division of: Vermont Marble, Granite, Slate & Soapstone Company. The unit is manufactured by Pecan Engineering Pty. Ltd out of Australia. We import the Bakers Oven into the United States and have named the stove The Vermont Bun Baker.

The Vermont Bun Baker has the firebox at the top and the oven below. Heat is directed around the oven by closing the damper, located next to the flue outlet.

Before lighting your Vermont Bun Baker ensure that the damper control is properly located so that it closes and swings open. The damper is open when the control lever is in the down position and closed in the up position. Also ensure that the steel inspection panel in the bottom of the oven is in place (not to be confused with the oven tray).

To light your cooker, first make sure that the damper is open and the air spindle control (the spindle control is opened and closed to control the rate of the burn) on the firebox door is also open to its full extent. Light a fire using finely chopped wood and establish it so that it has plenty of flames. As soon as the fire is going briskly, close the damper. This directs the flames and flue gases down the sides and around the oven. Keep the fire burning briskly until the oven is up to temperature. NOTE: The temperature gauge on the oven door is only a guide to the temperature in the oven. We have found that when the gauge is reading around 200 degrees Fahrenheit, the internal oven temperature is more like 350 degrees Fahrenheit. It is a good idea to use a meat thermometer when cooking. To add more fuel to the fire, it is advisable to open the damper before opening the door. When the firebox is loaded, close the door and then close the damper. This will avoid having smoke coming into the room.

For cooking, always have a brisk fire using small pieces of wood that provide plenty of flames. This type of fire will maintain the oven temperature. For heating and longer burn time, larger pieces of wood can be used and the spindle control closed off. The oven temperature will drop when in this mode of operation.

Operating Instructions for The Vermont Bun Baker

Maintenance

The Vermont Bun Baker requires little maintenance however; the flue and oven base should be periodically checked for soot/creosote buildup that may require cleaning. Inside the oven is a removable base plate. This plate should be lifted off and any soot underneath it removed. You can also remove the hotplates on the cooking surface of the Vermont Bun Baker and scrape the sides of the oven. The glass on the firebox and oven door can be cleaned with steel wool and water. It is not advisable to use a cleaner that contains caustic and abrasive cleaners. If you remove the glass to be cleaned please remember when you replace it, not to tighten the screws too tight to allow for heat expansion.

A metal strip at the top of the firebox door can be adjusted in and out with the Allen key provided. The strip should be set leaving a gap of about 1mm between the edge of the strip and the front of the Vermont Bun Baker. This gap allows a small trickle of air to wash over the glass.

Nectre Bakers Oven 5 year Warranty

Pecan Engineering Pty. Ltd., the manufacturer of the Nectre Bakers Oven, warrants this stove to be able to operate under normal use and service within 5 years from the date of the original purchase on the terms herein shall repair or replace, without cost to the original customer, any part thereof which shall be returned to our factory, transportation charges prepaid and which our inspection shows would prevent operation. This warranty does not apply to the firebricks, brick retainer, baffles, door seal, glass or discoloration of the surface or tarnishing of gold fittings all of which require normal service to maintain them.

Under the terms of this warranty, Pecan Engineering Pty. Ltd. assumes no responsibility for the labor costs involved in removing or replacing the stove. Nor shall Pecan Engineering Pty. Ltd. be liable for any injury, loss, or damage (direct, indirect or consequential) arising out of the use or inability to use the product, or its removal and replacement. All other stove warranties, expressed or implied, are excluded to the extent possible at law. Consumers also have rights under relevant State and Commonwealth Laws.

The Retailer does not have the authority to alter this warranty.

For further information, contact:
Vermont Woodstove Company
P.O. Box 723
10014 US RT 4 Whitehall, NY 12887
Ph: (518) 499-0160
Fax: (802) 419-8233

Operating Instructions for The Vermont Bun Baker

Safety Notices

When this room heater is not properly installed, a house fire may result. To reduce the risk of fire, follow the installation instructions. You will have to contact local building officials, fire officials, or any authority having jurisdiction about restrictions, permit and installation inspection requirements in your area.

DO NOT INSTALL IN A MOBILE HOME.

DO NOT USE CHEMICALS OR FLUIDS TO START THE FIRE.

DO NOT BURN GARBAGE OR FLAMMABLE FLUIDS SUCH AS GASOLINE, NAPHTHA OR ENGINE OIL.

HOT WHILE IN OPERATION. KEEP CHILDREN, CLOTHING AND FURNITURE AWAY.

CONTACT MAY CAUSE SKIN BURNS.

INSTALLATION

Before installation

After unpacking, check that the following parts are included inside the firebox:

2 side baffles

Top damper pig tail handle for air control

Lifter for cook plates

Allen key for adjustment of door air

Front damper handle for spindle control

Assembling the Bun Baker

The Bun Baker comes fully assembled. In transit, the side baffle plates could have shifted. Make sure that they are in place on each side of the firebox. The side baffles hang off the sides of the firebox. Also make sure that the firebricks at the back of the firebox are also in place and have not shifted in transit.

Operating Instructions for The Vermont Bun Baker

One of the main necessary precautions when installing a wood stove is to leave sufficient space between the stove (top, sides, back, front, and under stove pipes) and any other material that can catch fire.

If the stove is to be installed on a combustible floor, it must be placed on an approved 1" (25mm) non-combustible hearth pad with $k = 0.84 \text{ BTU/in ft}^2 \text{ hr } ^\circ\text{F}$. In the USA, the floor protector must extend 8" beyond each side of the flue loading door and 16" to the front. In Canada, the floor protector must extend 8" (200mm) beyond each side and the back of the appliance and 18" (450mm) to the front. (See fig. 4)




Fig. 4

In a rear vent installation the floor protection must also extend under the stovepipe a minimum of 2" (50mm) beyond either side of the pipe.


Operating Instructions for The Vermont Bun Baker

Installation Clearances


It is extremely important that you respect required installation distances and that you respect local installation regulations. This is for your safety! The manufacturer is not responsible for the product, if it is not installed following these recommendations. These clearances may only be reduced by means approved by the regulatory authority.

A combustible surface is anything that can burn (i.e. sheet rock, wall paper, wood, fabrics etc.) These surfaces are not limited to those that are visible and also include materials that are behind non-combustible materials. If you are not sure of the combustible nature of a material, consult your local fire officials.

Parallel Installation



Corner Installation



| | Single wall connector pipe | Double wall connector pipe |
|----------------------------------------|-------------------------------|-------------------------------|
| A – Chimney Connector to backwall | 16.5" (419 mm) | 10.5" (267 mm) |
| B – Chimney Connector to sidewall | 22" (559 mm) | 18" (457 mm) |
| C – Chimney Connector to cornerwall | 20" (508 mm) | 15" (381 mm) |
| D – Unit to backwall | 14" (356 mm) | 8" (203 mm) |
| E – Unit to sidewall | 14" (356 mm) | 10" (254 mm) |
| F – Unit to cornerwall | 11.5" (292 mm) | 6.5" (165 mm) |

Operating Instructions for The Vermont Bun Baker


Chimney connection

The chimney connector is a single walled pipe used to connect the stove to the chimney. For use with the Bun Baker, the chimney connector **MUST** be 6" in diameter, with a minimum thickness of 24 gauge black steel or 26 gauge blued steel.

Aluminum and galvanized steel pipe is not acceptable for use with the Bun Baker. These materials cannot withstand the extreme temperatures of a wood fire and can give off toxic fumes when heated.

Do not use the connector pipe as a chimney.

Each chimney connector or stovepipe section must be installed to the stove flue collar and to each other with the male (crimped) end toward the stove.



This prevents any amount of condensed or liquid creosote from running down the outside of the pipe or the stovetop. All joints, including the flue collar connection must be secured with three sheet metal screws to ensure that the sections do not separate.

For the best performance the chimney connector should be as short and direct as possible, with no more than two 90° elbows. The maximum horizontal run is 36" and a recommended total length of stovepipe should not exceed 10 feet. Always slope horizontal runs upward 1/4" per foot toward the chimney.

No part of the chimney connector may pass through an attic or roof space, closet or other concealed space, or through a floor ceiling. All sections of the chimney connectors must be accessible for cleaning. Where passage through a wall or partition of combustible construction is desired, the installation must conform to NFPA 211 or CAN/CSA-B365, and is also addressed in this manual.

Operating Instructions for The Vermont Bun Baker

Chimney

DO NOT CONNECT THIS UNIT TO A CHIMNEY FLUE SERVING ANOTHER APPLIANCE. DO NOT CONNECT TO ANY AIR DISTRIBUTION DUCT OR SYSTEM. This room heater must be connected to a 6" factory built UL 103 HT chimney (ULC S629, in Canada) or a code-approved masonry chimney with a flue liner.

Factory Built Chimney

When a metal prefabricated chimney is used, the manufacturer's installation instructions must be followed. You must also purchase (from the same manufacturer) and install the ceiling support package or wall pass-through and "T" section package, fire stops (where needed), insulation shield, roof flashing, chimney cap, etc. Maintain proper clearance to the structure as recommended by the manufacturer. The chimney must be the required height above the roof or other obstructions for safety and proper draft operation. See page 8 for chimney termination requirements.





FIGURE 9

Operating Instructions for The Vermont Bun Baker

Masonry Chimney

Ensure that a masonry chimney meets the minimum standards of the National Fire Protection Association (NFPA) by having it inspected by a professional. Make sure there are no cracks, loose mortar or other signs of deterioration and blockage. Have the chimney cleaned before the stove is installed and operated. When connecting the stove through a combustible wall to a masonry chimney, special methods are needed.



Masonry Fireplace

There are listed kits available to connect a stove to a masonry fireplace. The kit is an adapter that is installed at the location of the fireplace damper. The existing damper may have to be removed to allow installation. As the Bun Baker is not available in a rear flue option, installation into masonry can only be done if the height of the chimney opening exceeds the height of the Bun Baker.

Operating Instructions for The Vermont Bun Baker

Chimney Height

A masonry chimney or a listed factory-build chimney must be the required height above the roof and any other nearby obstructions. The chimney must be at least 3' (90 cm) higher than the highest point where it passes through the roof and at least 2' (60 cm) higher than the highest part of the roof or structure that is within 10' (305 cm) of the chimney, measured horizontally.

