


L10013AXX Coal Grate Complete

L10075AXX Coal Conversion Kit includes Grate

Appendix 2: Platerack & Splashback Parts List



Parts List

- | | |
|-------------------------------------|---------------------------------|
| 1. Blanking Cup – B00244AZZ | 5. RH Standard – B00246AZZ |
| 2. Slotted Rack Section – B00242AZZ | 6. Inner Splashback – F00684AXX |
| 3. Towel Rail – V00148AXX | 7. Outer Splashback – F00685AXX |
| 4. LH Standard – B00245AZZ | 8. Filler Section – B00243AZZ |


Fixings List

- 1/4" X 3/4" ROUND HEAD SCREWS x 4 - WARMING OVEN STANDARD TO HOB (Supplied with Cooker)
- 1/4" X 1" COUNTERSUNK SCREWS x 4 (WITH 1/4" NUTS x 4) – RACK SECTIONS TO FILLER SECTION
- 3/16" X 1/2" ROUND HEAD SCREWS x 4 - SPLASHBACK TO LH/RH STANDARD
- 3/16" NUTS & WASHERS x 4 - INNER SPLASHBACK TO LH & RH STANDARD
- No. 10 X 12MM SELF TAPPING SCREW x 4 - OUTER SPLASHBACK TO INNER SPLASHBACK
- No. 10 X 12MM SELF TAPPING SCREW x 4 – TOWEL RAIL TO LH & RH STANDARD

Appendix 3: Side Shelf Parts List

PARTS LIST

1. WARMING SHELF—B00241AXX
2. BRACKET TO SHELF—B00240BXX
3. 1/4 X 3/4" HEX HEAD BOLTS x 2
4. 3/8" WASHER x 1
5. 1/4" X 1" HEX HEAD BOLTS x 1
6. 1/4" X 1" ROUND HEAD SCREW x 1



Appendix 4: Warming Oven & Splashback Parts List

Warming Oven Parts List

- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Door End Piece – B00260AZZ 2. LH Cottage – B00262AZZ 3. RH Cottage – B00263AZZ 4. RH Towel Rail Bracket – B00265AZZ 5. Steel Straps – F00199AXX 6. LH Towel Rail Bracket – B00266AZZ 7. Door Back Panel – F00225AXX | <ol style="list-style-type: none"> 8. Outer Door Panel – F00226AXX 9. Warming Oven Body – F00229BXX 10. Warming Oven Standard – B00264AZZ 11. Spring Catch - V00128AXX 12. Ball Stud - V00157AXX 13. Handle – U00048AXX 14. Warming Oven Blanking Plate – F00831AXX |
|--|--|

Splashback Parts List

- | | |
|--|--|
| <ol style="list-style-type: none"> 15. Inner Splashback – F00227AXX | <ol style="list-style-type: none"> 16. Outer Splashback – F00228AXX |
|--|--|

Fixings List

- 1/4" X 3/4" ROUND HEAD SCREWS x 4 - WARMING OVEN STANDARD TO HOB (Supplied with Cooker)
- 1/4" X 1" COUNTERSUNK SCREWS x 4 (WITH 1/4" NUTS x 4) – STANDARD TO WARMING OVEN
- 1/4" X 3/4" HEX HEAD BOLT x 2 - TOWEL RAIL BRACKETS TO WARMING OVEN
- 3/16" X 1/2" ROUND HEAD SCREWS x 4 - SPLASHBACK TO WARMING OVEN STANDARD
- 3/16" NUTS & WASHERS x 4 - INNER SPLASHBACK TO WARMING OVEN STANDARD
- No. 10 X 12MM SELF TAPPING SCREW x 4 - OUTER SPLASHBACK TO INNER SPLASHBACK